

Flasher-C2000

- 1 **Install Flasher-C2000** Insert the *JTAGjet-C2000* CD into the drive. The Master Setup dialog box appears, providing access to the complete installation documentation. Select **Flasher-C2000 for JTAGjet**.
- 2 **Install USB driver** Plug the emulator into the USB port. If prompted by the *Found New Hardware* wizard, point to the **SigUSB.inf** file in the root of the CD. For details, see *USB 2.0 Driver for JTAGjet and ADM51: Installation Instructions* (*jtagjet_usb_install.pdf*).
- 3 **Start Flasher-C2000** Click the Windows Start button and select **Flash2800Win** or **Flash2400Win** from the *Signum Systems Flasher-C2000* program group.
- 4 **Uninstalling** You can uninstall Flasher-C2000 using *Add or Remove Programs* in Windows Control Panel (or equivalent). ■