



**IAR Embedded
Workbench**

IAR Assembler User Guide

for the 8051

Microcontroller Architecture

COPYRIGHT NOTICE

© 1991–2017 IAR Systems AB.

No part of this document may be reproduced without the prior written consent of IAR Systems AB. The software described in this document is furnished under a license and may only be used or copied in accordance with the terms of such a license.

DISCLAIMER

The information in this document is subject to change without notice and does not represent a commitment on any part of IAR Systems. While the information contained herein is assumed to be accurate, IAR Systems assumes no responsibility for any errors or omissions.

In no event shall IAR Systems, its employees, its contractors, or the authors of this document be liable for special, direct, indirect, or consequential damage, losses, costs, charges, claims, demands, claim for lost profits, fees, or expenses of any nature or kind.

TRADEMARKS

IAR Systems, IAR Embedded Workbench, IAR Connect, C-SPY, C-RUN, C-STAT, visualSTATE, IAR KickStart Kit, IAR Experiment!, I-jet, I-jet Trace, I-scope, IAR Academy, IAR, and the logotype of IAR Systems are trademarks or registered trademarks owned by IAR Systems AB.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

Intel® is a registered trademark of Intel Corporation.

Adobe and Acrobat Reader are registered trademarks of Adobe Systems Incorporated.

All other product names are trademarks or registered trademarks of their respective owners.

EDITION NOTICE

Ninth edition: March 2017

Part number: A8051-9

This guide applies to version 10.x of IAR Embedded Workbench® for the 8051 microcontroller architecture.

Internal reference: M21, Mym8.0, tut2017, asrct2010.3, V_110411, IJOA.

Contents

Tables	9
Preface	11
Who should read this guide	11
How to use this guide	11
What this guide contains	12
Document conventions	12
Typographic conventions	12
Naming conventions	13
Introduction to the IAR Assembler for 8051	15
Introduction to assembler programming	15
Getting started	15
Modular programming	16
External interface details	17
Assembler invocation syntax	17
Passing options	18
Environment variables	18
Error return codes	18
Source format	19
Expressions, operands, and operators	20
Integer constants	20
ASCII character constants	21
Floating-point constants	21
True and false	21
Symbols	22
Labels	22
Register symbols	23
Predefined symbols	23
Absolute and relocatable expressions	25
Expression restrictions	25

List file format	26
Header	26
Body	26
Summary	27
Symbol and cross-reference table	27
Programming hints	27
Accessing special function registers	27
Using C-style preprocessor directives	28
Tracking call frame usage	28
Call frame information overview	28
Call frame information in more detail	29
Defining a names block	30
Defining a common block	31
Annotating your source code within a data block	32
Specifying rules for tracking resources and the stack depth	32
Using CFI expressions for tracking complex cases	34
Examples of using CFI directives	35
Assembler options	39
Using command line assembler options	39
Specifying options and their parameters	39
Extended command line file	40
Summary of assembler options	40
Description of assembler options	41
-B	41
-c	42
-D	42
-E	43
-f	43
-G	44
-g	44
-I	44
-i	45
-L	45

-l	46
-M	46
-N	47
-n	47
--no_path_in_file_macros	48
-O	48
-o	49
-p	49
-r	50
-S	50
-s	50
--system_include_dir	51
-t	51
-U	51
-v	52
-w	53
-x	54
Assembler operators	55
Precedence of assembler operators	55
Summary of assembler operators	55
Parenthesis operator	55
Unary operators	56
Multiplicative arithmetic operators	56
Additive arithmetic operators	57
Shift operators	57
AND operators	57
OR operators	57
Comparison operators	57
Description of assembler operators	58
() Parenthesis	58
* Multiplication	58
+ Unary plus	59
+ Addition	59

- Unary minus	59
- Subtraction	59
/ Division	60
< Less than	60
<= Less than or equal	60
<>, != Not equal	61
=, == Equal	61
> Greater than	61
>= Greater than or equal	61
&& Logical AND	62
& Bitwise AND	62
~ Bitwise NOT	62
Bitwise OR	62
^ Bitwise exclusive OR	63
% Modulo	63
! Logical NOT	63
Logical OR	64
<< Logical shift left	64
>> Logical shift right	64
BYTE2 Second byte	64
BYTE3 Third byte	65
BYTE4 Fourth byte	65
DATE Current time/date	65
HIGH High byte	66
HWRD High word	66
LOC Local variable reference	66
LOW Low byte	67
LWRD Low word	67
PRM Parameter reference	67
SFB Segment begin	68
SFE Segment end	68
SIZEOF Segment size	69
UGT Unsigned greater than	69
ULT Unsigned less than	70

XOR Logical exclusive OR	70
Assembler directives	71
Summary of assembler directives	71
Description of assembler directives	75
Module control directives	75
Symbol control directives	79
Segment control directives	81
Value assignment directives	86
Conditional assembly directives	90
Macro processing directives	91
Listing control directives	99
C-style preprocessor directives	104
Data definition or allocation directives	108
Assembler control directives	110
Function directives	113
Call frame information directives for names blocks	114
Call frame information directives for common blocks	116
Call frame information directives for data blocks	117
Call frame information directives for tracking resources and CFAs	118
Assembler diagnostics	123
Message format	123
Severity levels	123
Options for diagnostics	123
Assembly warning messages	123
Command line error messages	123
Assembly error messages	124
Assembly fatal error messages	124
Assembler internal error messages	124
Index	125

Tables

1: Typographic conventions used in this guide	12
2: Naming conventions used in this guide	13
3: Assembler environment variables	18
4: Assembler error return codes	18
5: Integer constant formats	20
6: ASCII character constant formats	21
7: Floating-point constants	21
8: Predefined register symbols	23
9: Predefined symbols	23
10: Symbol and cross-reference table	27
11: Code sample with call frame information	35
12: Assembler options summary	40
13: Assembler directives summary	71
14: Module control directives	76
15: Symbol control directives	79
16: Segment control directives	83
17: Value assignment directives	87
18: Macro processing directives	92
19: Listing control directives	100
20: C-style preprocessor directives	104
21: Data definition or allocation directives	109
22: Assembler control directives	111
23: Function directives	114
24: Call frame information directives names block	115
25: Call frame information directives common block	117
26: Call frame information directives for data blocks	118
27: Unary operators in CFI expressions	119
28: Binary operators in CFI expressions	119
29: Ternary operators in CFI expressions	120
30: Call frame information directives for tracking resources and CFAs	121

Preface

Welcome to the IAR Assembler User Guide for 8051. The purpose of this guide is to provide you with detailed reference information that can help you to use the IAR Assembler for 8051 to develop your application according to your requirements.

Who should read this guide

You should read this guide if you plan to develop an application, or part of an application, using assembler language for the 8051 microcontroller and need to get detailed reference information on how to use the IAR Assembler for 8051. In addition, you should have working knowledge of the following:

- The architecture and instruction set of the 8051 microcontroller (refer to the chip manufacturer's documentation)
- General assembler language programming
- Application development for embedded systems
- The operating system of your host computer.

How to use this guide

When you first begin using the IAR Assembler for 8051, you should read the chapter *Introduction to the IAR Assembler for 8051*.

If you are an intermediate or advanced user, you can focus more on the reference chapters that follow the introduction.

If you are new to using the IAR Embedded Workbench, we recommend that you first work through the tutorials, which you can find in the IAR Information Center and which will help you get started using IAR Embedded Workbench.

What this guide contains

Below is a brief outline and summary of the chapters in this guide.

- *Introduction to the IAR Assembler for 8051* provides programming information. It also describes the source code format, and the format of assembler listings.
- *Assembler options* first explains how to set the assembler options from the command line and how to use environment variables. It then gives an alphabetical summary of the assembler options, and contains detailed reference information about each option.
- *Assembler operators* gives a summary of the assembler operators, arranged in order of precedence, and provides detailed reference information about each operator.
- *Assembler directives* gives an alphabetical summary of the assembler directives, and provides detailed reference information about each of the directives, classified into groups according to their function.
- *Assembler diagnostics* contains information about the formats and severity levels of diagnostic messages.

Document conventions

When, in the IAR Systems documentation, we refer to the programming language C, the text also applies to C++, unless otherwise stated.

When referring to a directory in your product installation, for example `8051\doc`, the full path to the location is assumed, for example `c:\Program Files\IAR Systems\Embedded Workbench N.n\8051\doc`, where the initial digit of the version number reflects the initial digit of the version number of the IAR Embedded Workbench shared components.

TYPOGRAPHIC CONVENTIONS

The IAR Systems documentation set uses the following typographic conventions:

Style	Used for
<code>computer</code>	<ul style="list-style-type: none"> • Source code examples and file paths. • Text on the command line. • Binary, hexadecimal, and octal numbers.
<code>parameter</code>	A placeholder for an actual value used as a parameter, for example <code>filename.h</code> where <code>filename</code> represents the name of the file.
<code>[option]</code>	An optional part of a directive, where <code>[</code> and <code>]</code> are not part of the actual directive, but any <code>,</code> <code>{</code> , or <code>}</code> are part of the directive syntax.

Table 1: Typographic conventions used in this guide





Style	Used for
<code>{option}</code>	A mandatory part of a directive, where { and } are not part of the actual directive, but any [,], {, or } are part of the directive syntax.
<code>[option]</code>	An optional part of a command.
<code>[a b c]</code>	An optional part of a command with alternatives.
<code>{a b c}</code>	A mandatory part of a command with alternatives.
bold	Names of menus, menu commands, buttons, and dialog boxes that appear on the screen.
<i>italic</i>	<ul style="list-style-type: none"> • A cross-reference within this guide or to another guide. • Emphasis.
...	An ellipsis indicates that the previous item can be repeated an arbitrary number of times.
	Identifies instructions specific to the IAR Embedded Workbench® IDE interface.
	Identifies instructions specific to the command line interface.
	Identifies helpful tips and programming hints.
	Identifies warnings.

Table 1: Typographic conventions used in this guide (Continued)

NAMING CONVENTIONS

The following naming conventions are used for the products and tools from IAR Systems®, when referred to in the documentation:

Brand name	Generic term
IAR Embedded Workbench® for 8051	IAR Embedded Workbench®
IAR Embedded Workbench® IDE for 8051	the IDE
IAR C-SPY® Debugger for 8051	C-SPY, the debugger
IAR C-SPY® Simulator	the simulator
IAR C/C++ Compiler™ for 8051	the compiler
IAR Assembler™ for 8051	the assembler
IAR XLINK Linker™	XLINK, the linker
IAR XAR Library Builder™	the library builder
IAR XLIB Librarian™	the librarian
IAR DLIB Runtime Environment™	the DLIB runtime environment

Table 2: Naming conventions used in this guide

Brand name	Generic term
IAR CLIB Runtime Environment™	the CLIB runtime environment

Table 2: Naming conventions used in this guide (Continued)

Note: In this guide, *8051 microcontroller* refers to all microcontrollers compatible with the 8051 microcontroller architecture.

Introduction to the IAR Assembler for 8051

- Introduction to assembler programming
- Modular programming
- External interface details
- Source format
- Expressions, operands, and operators
- List file format
- Programming hints
- Tracking call frame usage

Introduction to assembler programming

Even if you do not intend to write a complete application in assembler language, there might be situations where you find it necessary to write parts of the code in assembler, for example, when using mechanisms in the 8051 microcontroller that require precise timing and special instruction sequences.

To write efficient assembler applications, you should be familiar with the architecture and instruction set of the 8051 microcontroller. Refer to the chip manufacturer's hardware documentation for syntax descriptions of the instruction mnemonics.

GETTING STARTED

To ease the start of the development of your assembler application, you can:

- Work through the tutorials—especially the one about mixing C and assembler modules—that you find in the Information Center
- Read about the assembler language interface—also useful when mixing C and assembler modules—in the *IAR C/C++ Compiler User Guide for 8051*
- In the IAR Embedded Workbench IDE, you can base a new project on a *template* for an assembler project.

Modular programming

It is widely accepted that modular programming is a prominent feature of good software design. If you structure your code in small modules—in contrast to one single monolith—you can organize your application code in a logical structure, which makes the code easier to understand, and which aids:

- efficient program development
- reuse of modules
- maintenance.

The IAR development tools provide different facilities for achieving a modular structure in your software.

Typically, you write your assembler code in assembler source files. In each source file you define one or several assembler *modules*, using the module control directives. Each module has a name and a type, where the type can be either `PROGRAM` or `LIBRARY`. The linker always includes a `PROGRAM` module, whereas a `LIBRARY` module is only included in the linked code if other modules refer to a public symbol in the module. You can divide each module further into subroutines.

A *segment* is a logical entity containing a piece of data or code that should be mapped to a physical location in memory. Use the segment control directives to place your code and data in segments. A segment can be either *absolute* or *relocatable*. An absolute segment always has a fixed address in memory, whereas the address for a relocatable segment is resolved at link time. Segments let you control how your code and data is placed in memory. Each segment consists of many *segment parts*. A segment part is the smallest linkable unit, which allows the linker to include only those units that are referred to.

If you are working on a large project you will soon accumulate a collection of useful routines that are used by several of your applications. To avoid ending up with a huge amount of small object files, collect modules that contain such routines in a *library* object file. In the IAR Embedded Workbench IDE, you can set up a library project, to collect many object files in one library. For an example, see the tutorials in the Information Center.

To summarize, your software design benefits from modular programming, and to achieve a modular structure you can:

- Create many small modules, either one per source file, or many modules per file by using the module directives
- In each module, divide your assembler source code into small subroutines (corresponding to *functions* on the C level)

- Divide your assembler source code into *segments*, to gain more precise control of how your code and data finally is placed in memory
- Collect your routines in libraries, which means that you can reduce the number of object files and make the modules conditionally linked.

External interface details

This section provides information about how the assembler interacts with its environment:

- *Assembler invocation syntax*, page 17
- *Passing options*, page 18
- *Environment variables*, page 18
- *Error return codes*, page 18

You can use the assembler either from the IAR Embedded Workbench IDE or from the command line. Refer to the *IAR Project Management and Building Guide for 8051* for information about using the assembler from the IAR Embedded Workbench IDE.

ASSEMBLER INVOCATION SYNTAX

The invocation syntax for the assembler is:

```
a8051 [options][sourcefile][options]
```

For example, when assembling the source file `prog.s51`, use this command to generate an object file with debug information:

```
a8051 prog -r
```

By default, the IAR Assembler for 8051 recognizes the filename extensions `s51`, `asm`, and `msa` for source files. The default filename extension for assembler output is `r51`.

Generally, the order of options on the command line, both relative to each other and to the source filename, is not significant. However, there is one exception: when you use the `-I` option, the directories are searched in the same order that they are specified on the command line.

If you run the assembler from the command line without any arguments, the assembler version number and all available options including brief descriptions are directed to `stdout` and displayed on the screen.

PASSING OPTIONS

You can pass options to the assembler in three different ways:

- Directly from the command line
 - Specify the options on the command line after the `a8051` command; see *Assembler invocation syntax*, page 17.
- Via environment variables
 - The assembler automatically appends the value of the environment variables to every command line, so it provides a convenient method of specifying options that are required for every assembly; see *Environment variables*, page 18.
- Via a text file by using the `-f` option; see *-f*, page 43.

For general guidelines for the option syntax, an options summary, and more information about each option, see the *Assembler options* chapter.

ENVIRONMENT VARIABLES

You can use these environment variables with the IAR Assembler:

Environment variable	Description
ASM8051	Specifies command line options; for example: <code>set ASM8051=-L -ws</code>
A8051_INC	Specifies directories to search for include files; for example: <code>set A8051_INC=c:\myinc\</code>

Table 3: Assembler environment variables

For example, setting this environment variable always generates a list file with the name `temp.lst`:

```
set ASM8051=-l temp.lst
```

For information about the environment variables used by the IAR XLINK Linker and the IAR XLIB Librarian, see the *IAR Linker and Library Tools Reference Guide*.

ERROR RETURN CODES

When using the IAR Assembler from within a batch file, you might have to determine whether the assembly was successful to decide what step to take next. For this reason, the assembler returns these error return codes:

Return code	Description
0	Assembly successful, warnings might appear.
1	Warnings occurred (only if the <code>-ws</code> option is used).

Table 4: Assembler error return codes

Return code	Description
2	Errors occurred.

Table 4: Assembler error return codes (Continued)

Source format

The format of an assembler source line is as follows:

```
[label [:]] [operation] [operands] [; comment]
```

where the components are as follows:

<i>label</i>	A definition of a label, which is a symbol that represents an address. If the label starts in the first column—that is, at the far left on the line—the <code>:</code> (colon) is optional.
<i>operation</i>	An assembler instruction or directive. This must not start in the first column—there must be some whitespace to the left of it.
<i>operands</i>	An assembler instruction or data definition directive (for example <code>DB</code> or <code>DC8</code>) can have zero, one, or more operands. The operands are separated by commas. An operand can be: <ul style="list-style-type: none"> • a constant representing a numeric value or an address • a symbolic name representing a numeric value or an address (where the latter also is referred to as a label) • a register • a predefined symbol • the program location counter (<code>PLC</code>) • an expression. Other directives can have one, two, or three operands, separated by commas.
<i>comment</i>	Comment, preceded by a <code>;</code> (semicolon) C or C++ comments are also allowed.

The components are separated by spaces or tabs.

A source line cannot exceed 2047 characters.

Tab characters, ASCII 09H, are expanded according to the most common practice; i.e. to columns 8, 16, 24 etc. This affects the source code output in list files and debug information. Because tabs might be set up differently in different editors, do not use tabs in your source files.

Expressions, operands, and operators

Expressions consist of expression operands and operators.

The assembler accepts a wide range of expressions, including both arithmetic and logical operations. All operators use 32-bit two's complement integers. Range checking is performed if a value is used for generating code.

Expressions are evaluated from left to right, unless this order is overridden by the priority of operators; see also *Assembler operators*.

These operands are valid in an expression:

- Constants for data or addresses, excluding floating-point constants.
- Symbols—symbolic names—which can represent either data or addresses, where the latter also is referred to as *labels*.
- The program location counter (PLC), \$ (dollar).

The operands are described in greater details on the following pages.

INTEGER CONSTANTS

Because all IAR Systems assemblers use 32-bit two's complement internal arithmetic, integers have a (signed) range from -2147483648 to 2147483647.

Constants are written as a sequence of digits with an optional - (minus) sign in front to indicate a negative number.

Commas and decimal points are not permitted.

The following types of number representation are supported:

Integer type	Example
Binary	1010b, b' 1010
Octal	1234q, q' 1234
Decimal	1234, -1, d' 1234
Hexadecimal	0FFFFh, 0xFFFF, h' FFFF

Table 5: Integer constant formats

Note: Both the prefix and the suffix can be written with either uppercase or lowercase letters.

SYMBOLS

User-defined symbols can be up to 255 characters long, and all characters are significant. Depending on what kind of operation a symbol is followed by, the symbol is either a data symbol or an address symbol where the latter is referred to as a label. A symbol before an instruction is a label and a symbol before, for example the `EQU` directive, is a data symbol. A symbol can be:

- absolute—its value is known by the assembler
- relocatable—its value is resolved at link time.

Symbols must begin with a letter, a–z or A–Z, ? (question mark), or _ (underscore). Symbols can include the digits 0–9 and \$ (dollar).

Symbols may contain any printable characters if they are quoted with ` (backquote), for example:

```
`strange#label`
```

Case is insignificant for built-in symbols like instructions, registers, operators, and directives. For user-defined symbols, case is by default significant but can be turned on and off using the **Case sensitive user symbols** (`-s`) assembler option. For more information, see `-s`, page 50.

Use the symbol control directives to control how symbols are shared between modules. For example, use the `PUBLIC` directive to make one or more symbols available to other modules. The `EXTERN` directive is used for importing an untyped external symbol.

Note that symbols and labels are byte addresses. See also *Data definition or allocation directives*, page 108.

LABELS

Symbols used for memory locations are referred to as labels.

Program location counter (PLC)

The assembler keeps track of the start address of the current instruction. This is called the *program location counter*.

If you must refer to the program location counter in your assembler source code, use the \$ (dollar) sign. For example:

```
SJMP $ ; Loop forever
```

REGISTER SYMBOLS

This table shows the existing predefined register symbols:

Name	Size	Description
R0–R7	8-bit	Data registers
A	8-bit	Data register
B	8-bit	Data register or SFR address of register B
ACC	8-bit	SFR address of register A
DPL	8-bit	SFR address of the low part of register DPTR
DPH	8-bit	SFR address of the high part of register DPTR
PSW	8-bit	SFR address of register PSW (program status word)

Table 8: Predefined register symbols

PREDEFINED SYMBOLS

The IAR Assembler for 8051 defines a set of symbols for use in assembler source files. The symbols provide information about the current assembly, allowing you to test them in preprocessor directives or include them in the assembled code.

These predefined symbols are available:

Symbol	Value
<code>__A8051__</code>	An integer that is set to 1 when the code is assembled with the IAR Assembler for 8051.
<code>__BUILD_NUMBER__</code>	A unique integer that identifies the build number of the assembler currently in use. The build number does not necessarily increase with an assembler that is released later.
<code>__DATE__</code>	The current date in <code>dd/Mmm/yyyy</code> format (string).
<code>__FILE__</code>	The name of the current source file (string).
<code>__IAR_SYSTEMS_ASM__</code>	IAR assembler identifier (number). Note that the number could be higher in a future version of the product. This symbol can be tested with <code>#ifdef</code> to detect whether the code was assembled by an assembler from IAR Systems.
<code>__LINE__</code>	The current source line number (number).

Table 9: Predefined symbols

Symbol	Value
<code>__TID__</code>	Target identity, consisting of two bytes (number). The high byte is the target identity, which is 32 for a8051. The low byte is the processor option *16. These values are therefore possible: -v0 0x2000 -v1 0x2010 -v2 0x2020
<code>__SUBVERSION__</code>	An integer that identifies the subversion number of the assembler version number, for example 3 in 1.2.3.4.
<code>__TIME__</code>	The current time in hh:mm:ss format (string).
<code>__VER__</code>	The version number in integer format; for example, version 4.17 is returned as 417 (number).

Table 9: Predefined symbols (Continued)

Including symbol values in code

Several data definition directives make it possible to include a symbol value in the code. These directives define values or reserve memory. To include a symbol value in the code, use the symbol in the appropriate data definition directive.

For example, to include the time of assembly as a string for the program to display:

```

RSEG    DATA
td      DB      __TIME__, ", ", __DATE__, 0 ; time and date
RSEG    CODE
EXTERN  printstring
main
MOV     A, #td           ; load address of string
MOV     R1, A
LCALL  printstring      ; routine to print string
RET
```

Testing symbols for conditional assembly

To test a symbol at assembly time, use one of the conditional assembly directives. These directives let you control the assembly process at assembly time.

For example, if you want to assemble separate code sections depending on whether you are using an old assembler version or a new assembler version, do as follows:

```
#if (__VER__ > 300)                ; New assembler version
;...
;...
#else                               ; Old assembler version
;...
;...
#endif
```

For more information, see *Conditional assembly directives*, page 90.

ABSOLUTE AND RELOCATABLE EXPRESSIONS

Depending on what operands an expression consists of, the expression is either *absolute* or *relocatable*. Absolute expressions are those expressions that only contain absolute symbols or relocatable symbols that cancel each other out.

Expressions that include symbols in relocatable segments cannot be resolved at assembly time, because they depend on the location of segments. These are referred to as relocatable expressions.

Such expressions are evaluated and resolved at link time, by the IAR XLINK Linker. There are no restrictions on the expression; any operator can be used on symbols from any segment, or any combination of segments.

For example, a program could define absolute and relocatable expressions as follows:

```
                                name    simpleExpressions
                                rseg    CONST:CONST
                                extern  size
first    dc8    5                ; A relocatable label.
second   equ    10 + 5          ; An absolute expression.

                                dc8    first           ; Examples of some legal
                                dc8    first + 1       ; relocatable expressions.
                                dc8    first + second
                                dc8    first + 8 * size
                                end
```

Note: At assembly time, there is no range check. The range check occurs at link time and, if the values are too large, there is a linker error.

EXPRESSION RESTRICTIONS

Expressions can be categorized according to restrictions that apply to some of the assembler directives. One such example is the expression used in conditional statements

like `IF`, where the expression must be evaluated at assembly time and therefore cannot contain any external symbols.

The following expression restrictions are referred to in the description of each directive they apply to.

No forward

All symbols referred to in the expression must be known, no forward references are allowed.

No external

No external references in the expression are allowed.

Absolute

The expression must evaluate to an absolute value; a relocatable value (segment offset) is not allowed.

Fixed

The expression must be fixed, which means that it must not depend on variable-sized instructions. A variable-sized instruction is an instruction that might vary in size depending on the numeric value of its operand.

List file format

The format of an assembler list file is as follows:

HEADER

The header section contains product version information, the date and time when the file was created, and which options were used.

BODY

The body of the listing contains the following fields of information:

- The line number in the source file. Lines generated by macros, if listed, have a . (period) in the source line number field.
- The address field shows the location in memory, which can be absolute or relative depending on the type of segment. The notation is hexadecimal.

- The data field shows the data generated by the source line. The notation is hexadecimal. Unresolved values are represented by (periods), where two periods signify one byte. These unresolved values are resolved during the linking process.
- The assembler source line.

SUMMARY

The end of the file contains a summary of errors and warnings that were generated.

SYMBOL AND CROSS-REFERENCE TABLE

When you specify the **Include cross-reference** option, or if the `LSTXRF+` directive was included in the source file, a symbol and cross-reference table is produced.

This information is provided for each symbol in the table:

Information	Description
Symbol	The symbol's user-defined name.
Mode	ABS (Absolute), or REL (Relocatable).
Segments	The name of the segment that this symbol is defined relative to.
Value/Offset	The value (address) of the symbol within the current module, relative to the beginning of the current segment part.

Table 10: Symbol and cross-reference table

Programming hints

This section gives hints on how to write efficient code for the IAR Assembler. For information about projects including both assembler and C or C++ source files, see the *IAR C/C++ Compiler User Guide for 8051*.

ACCESSING SPECIAL FUNCTION REGISTERS

Specific header files for several 8051 devices are included in the IAR Systems product package, in the `8051\inc` directory. These header files define the processor-specific special function registers (SFRs) and interrupt vector numbers.

The header files are intended to be used also with the IAR C/C++ Compiler for 8051, and they are suitable to use as templates when creating new header files for other 8051 derivatives.

If any assembler-specific additions are needed in the header file, you can easily add these in the assembler-specific part of the file:

```
#ifndef __IAR_SYSTEMS_ASM__
    ; Add your assembler-specific defines here.
#endif
```

USING C-STYLE PREPROCESSOR DIRECTIVES

The C-style preprocessor directives are processed before other assembler directives. Therefore, do not use preprocessor directives in macros and do not mix them with assembler-style comments. For more information about comments, see *Assembler control directives*, page 110.

C-style preprocessor directives like `#define` are valid in the remainder of the source code file, while assembler directives like `EQU` only are valid in the current module.

Tracking call frame usage

In this section, these topics are described::

- *Call frame information overview*, page 28
- *Call frame information in more detail*, page 29

These tasks are described:

- *Defining a names block*, page 30
- *Defining a common block*, page 31
- *Annotating your source code within a data block*, page 32
- *Specifying rules for tracking resources and the stack depth*, page 32
- *Using CFI expressions for tracking complex cases*, page 34
- *Examples of using CFI directives*, page 35

For reference information, see:

- *Call frame information directives for names blocks*, page 114
- *Call frame information directives for common blocks*, page 116
- *Call frame information directives for data blocks*, page 117
- *Call frame information directives for tracking resources and CFAs*, page 118

CALL FRAME INFORMATION OVERVIEW

Call frame information (CFI) is information about the *call frames*. Typically, a call frame contains a return address, function arguments, saved register values, compiler

temporaries, and local variables. Call frame information holds enough information about call frames to support two important features:

- C-SPY can use call frame information to reconstruct the entire call chain from the current PC (program counter) and show the values of local variables in each function in the call chain.
- Call frame information can be used, together with information about possible calls for calculating the total stack usage in the application. Note that this feature might not be supported by the product you are using.

The compiler automatically generates call frame information for all C and C++ source code. Call frame information is also typically provided for each assembler routine in the system library. However, if you have other assembler routines and want to enable C-SPY to show the call stack when executing these routines, you must add the required call frame information annotations to your assembler source code. Stack usage can also be handled this way (by adding the required annotations for each function call), but you can also specify stack usage information for any routines in a *stack usage control file* (see the *IAR C/C++ Compiler User Guide for 8051*), which is typically easier.

CALL FRAME INFORMATION IN MORE DETAIL

You can add call frame information to assembler files by using `cfi` directives. You can use these to specify:

- The *start address* of the call frame, which is referred to as the *canonical frame address* (CFA). There are two different types of call frames:
 - On a stack—*stack frames*. For stack frames the CFA is typically the value of the stack pointer after the return from the routine.
 - In static memory, as used in a static overlay system—*static overlay frames*. This type of call frame is not required by the 8051 microcontroller and is thus not supported.
- How to find the return address.
- How to restore various resources, like registers, when returning from the routine.

When adding the call frame information for each assembler module, you must:

- 1 Provide a *names block* where you describe the resources to be tracked.
- 2 Provide a *common block* where you define the resources to be tracked and specify their default values. This information must correspond to the calling convention used by the compiler.

- 3 Annotate the resources used in your source code, which in practice means that you describe the changes performed on the call frame. Typically, this includes information about when the stack pointer is changed, and when permanent registers are stored or restored on the stack.

To do this you must define a *data block* that encloses a continuous piece of source code where you specify *rules* for each resource to be tracked. When the descriptive power of the rules is not enough, you can instead use *CFI expressions*.

A full description of the calling convention might require extensive call frame information. In many cases, a more limited approach will suffice. The recommended way to create an assembler language routine that handles call frame information correctly is to start with a C skeleton function that you compile to generate assembler output. For an example, see the *IAR C/C++ Compiler User Guide for 8051*.

DEFINING A NAMES BLOCK

A *names block* is used for declaring the resources available for a processor. Inside the names block, all resources that can be tracked are defined.

Start and end a names block with the directives:

```
CFI NAMES name
CFI ENDNAMES name
```

where *name* is the name of the block.

Only one names block can be open at a time.

Inside a names block, four different kinds of declarations can appear: a resource declaration, a stack frame declaration, a static overlay frame declaration, and a base address declaration:

- To declare a resource, use one of the directives:

```
CFI RESOURCE resource : bits
CFI VIRTUALRESOURCE resource : bits
```

The parameters are the name of the resource and the size of the resource in bits. A virtual resource is a logical concept, in contrast to a “physical” resource such as a processor register. Virtual resources are usually used for the return address.

To declare more than one resource, separate them with commas.

A resource can also be a composite resource, made up of at least two parts. To declare the composition of a composite resource, use the directive:

```
CFI RESOURCEPARTS resource part, part, ...
```

The parts are separated with commas. The resource and its parts must have been previously declared as resources, as described above.

- To declare a stack frame CFA, use the directive:

```
CFI STACKFRAME cfa resource type
```

The parameters are the name of the stack frame CFA, the name of the associated resource (the stack pointer), and the memory type (to get the address space). To declare more than one stack frame CFA, separate them with commas.

When going “back” in the call stack, the value of the stack frame CFA is copied into the associated stack pointer resource to get a correct value for the previous function frame.

- To declare a static overlay frame CFA, use the directive:

```
CFI STATICOVERLAYFRAME cfa segment
```

The parameters are the name of the CFA and the name of the segment where the static overlay for the function is located. To declare more than one static overlay frame CFA, separate them with commas.

DEFINING A COMMON BLOCK

The *common block* is used for declaring the initial contents of all tracked resources. Normally, there is one common block for each calling convention used.

Start a common block with the directive:

```
CFI COMMON name USING namesblock
```

where *name* is the name of the new block and *namesblock* is the name of a previously defined names block.

Declare the return address column with the directive:

```
CFI RETURNADDRESS resource type
```

where *resource* is a resource defined in *namesblock* and *type* is the memory in which the calling function resides. You must declare the return address column for the common block.

Inside a common block, you can declare the initial value of a CFA or a resource by using the directives available for common blocks, see *Call frame information directives for common blocks*, page 116. For more information about how to use these directives, see *Specifying rules for tracking resources and the stack depth*, page 32 and *Using CFI expressions for tracking complex cases*, page 34.

End a common block with the directive:

```
CFI ENDCOMMON name
```

where *name* is the name used to start the common block.

ANNOTATING YOUR SOURCE CODE WITHIN A DATA BLOCK

The *data block* contains the actual tracking information for one continuous piece of code.

Start a data block with the directive:

```
CFI BLOCK name USING commonblock
```

where *name* is the name of the new block and *commonblock* is the name of a previously defined common block.

If the piece of code for the current data block is part of a defined function, specify the name of the function with the directive:

```
CFI FUNCTION label
```

where *label* is the code label starting the function.

If the piece of code for the current data block is not part of a function, specify this with the directive:

```
CFI NOFUNCTION
```

End a data block with the directive:

```
CFI ENDBLOCK name
```

where *name* is the name used to start the data block.

Inside a data block, you can manipulate the values of the resources by using the directives available for data blocks, see *Call frame information directives for data blocks*, page 117. For more information on how to use these directives, see *Specifying rules for tracking resources and the stack depth*, page 32, and *Using CFI expressions for tracking complex cases*, page 34.

SPECIFYING RULES FOR TRACKING RESOURCES AND THE STACK DEPTH

To describe the tracking information for individual resources, two sets of simple rules with specialized syntax can be used:

- Rules for tracking resources

```
CFI resource { UNDEFINED | SAMEVALUE | CONCAT }
```

```
CFI resource { resource | FRAME(cfa, offset) }
```

- Rules for tracking the stack depth (CFAs)

```
CFI cfa { NOTUSED | USED }
```

```
CFI cfa { resource | resource + constant | resource - constant }
```


You can use these rules both in common blocks to describe the initial information for resources and CFAs, and inside data blocks to describe changes to the information for resources or CFAs.

In those rare cases where the descriptive power of the simple rules are not enough, you can use a full *CFI expression* with dedicated *operators* to describe the information, see *Using CFI expressions for tracking complex cases*, page 34. However, whenever possible, you should always use a rule instead of a CFI expression.

Rules for tracking resources

The rules for resources conceptually describe where to find a resource when going back one call frame. For this reason, the item following the resource name in a CFI directive is referred to as the *location* of the resource.

To declare that a tracked resource is restored, in other words, already correctly located, use `SAMEVALUE` as the location. Conceptually, this declares that the resource does not have to be restored because it already contains the correct value. For example, to declare that a register `R11` is restored to the same value, use the directive:

```
CFI R11 SAMEVALUE
```

To declare that a resource is not tracked, use `UNDEFINED` as location. Conceptually, this declares that the resource does not have to be restored (when going back one call frame) because it is not tracked. Usually it is only meaningful to use it to declare the initial location of a resource. For example, to declare that `R11` is a scratch register and does not have to be restored, use the directive:

```
CFI R11 UNDEFINED
```

To declare that a resource is temporarily stored in another resource, use the resource name as its location. For example, to declare that a register `R11` is temporarily located in a register `R12` (and should be restored from that register), use the directive:

```
CFI R11 R12
```

To declare that a resource is currently located somewhere on the stack, use `FRAME(cfa, offset)` as location for the resource, where *cfa* is the CFA identifier to use as “frame pointer” and *offset* is an offset relative the CFA. For example, to declare that a register `R11` is located at offset `-4` counting from the frame pointer `CFA_SP`, use the directive:

```
CFI R11 FRAME(CFA_SP, -4)
```

For a composite resource there is one additional location, `CONCAT`, which declares that the location of the resource can be found by concatenating the resource parts for the composite resource. For example, consider a composite resource `RET` with resource

parts `RETLO` and `RETHI`. To declare that the value of `RET` can be found by investigating and concatenating the resource parts, use the directive:

```
CFI RET CONCAT
```

This requires that at least one of the resource parts has a definition, using the rules described above.

Rules for tracking the stack depth (CFAs)

In contrast to the rules for resources, the rules for CFAs describe the address of the beginning of the call frame. The call frame often includes the return address pushed by the assembler call instruction. The CFA rules describe how to compute the address of the beginning of the current stack frame.

Each stack frame CFA is associated with a stack pointer. When going back one call frame, the associated stack pointer is restored to the current CFA. For stack frame CFAs there are two possible rules: an offset from a resource (not necessarily the resource associated with the stack frame CFA) or `NOTUSED`.

To declare that a CFA is not used, and that the associated stack pointer should be tracked as a normal resource, use `NOTUSED` as the address of the CFA. For example, to declare that the CFA with the name `CFA_SP` is not used in this code block, use the directive:

```
CFI CFA_SP NOTUSED
```

To declare that a CFA has an address that is offset relative the value of a resource, specify the stack pointer and the offset. For example, to declare that the CFA with the name `CFA_SP` can be obtained by adding 4 to the value of the `SP` resource, use the directive:

```
CFI CFA_SP SP + 4
```

For static overlay frame CFAs, there are only two possible declarations inside common and data blocks: `USED` and `NOTUSED`.

USING CFI EXPRESSIONS FOR TRACKING COMPLEX CASES

You can use *call frame information expressions* (CFI expressions) when the descriptive power of the rules for resources and CFAs is not enough. However, you should always use a simple rule if there is one.

CFI expressions consist of operands and operators. Three sets of operators are allowed in a CFI expression:

- Unary operators
- Binary operators
- Ternary operators

In most cases, they have an equivalent operator in the regular assembler expressions.

In this example, R12 is restored to its original value. However, instead of saving it, the effect of the two post increments is undone by the subtract instruction.

```
AddTwo:
    cfi block addTwoBlock using myCommon
    cfi function addTwo
    cfi nocalhs
    cfi r12 samevalue
    add @r12+, r13
    cfi r12 sub(r12, 2)
    add @r12+, r13
    cfi r12 sub(r12, 4)
    sub #4, r12
    cfi r12 samevalue
    ret
    cfi endblock addTwoBlock
```

For more information about the syntax for using the operators in CFI expressions, see *Call frame information directives for tracking resources and CFAs*, page 118.

EXAMPLES OF USING CFI DIRECTIVES

The following is a generic example of how to add and use the required CFI directives. The example is not specific to the 8051 microcontroller. To obtain an example specific to the microcontroller you are using, generate assembler output when you compile a C source file.

Consider a generic processor with a stack pointer SP, and two registers R0 and R1. Register R0 is used as a scratch register (the register may be destroyed by a function call), whereas register R1 must be restored after the function call. To simplify, all instructions, registers, and addresses are assumed to have a width of 16 bits.

Consider the following short code example with the corresponding call frame information. At entry, assume that the stack contains a 16-bit return address. The stack grows from high addresses toward zero. The CFA denotes the top of the call frame, in other words, the value of the stack pointer after returning from the function.

Address	CFA	R0	R1	RET	Assembler code
0000	SP + 2	Undefined	SAME	CFA - 2	func1: PUSH R1
0002	SP + 4		CFA - 4		MOV R1, #4
0004					CALL func2
0006					POP R0
0008	SP + 2		R0		MOV R1, R0
000A			SAME		RET

Table 11: Code sample with call frame information

Each row describes the state of the tracked resources *before* the execution of the instruction. As an example, for the `MOV R1, R0` instruction the original value of the R1 register is located in the R0 register and the top of the function frame (the CFA column) is `SP + 2`. The row at address 0000 is the initial row and the result of the calling convention used for the function.

The RET column is the return address column—that is, the location of the return address. The value of R0 is undefined because it does not need to be restored on exit from the function. The R1 column has `SAME` in the initial row to indicate that the value of the R1 register will be restored to the same value it already has.

Defining the names block

The names block for the small example above would be:

```

cfi      names trivialNames
cfi      resource SP:16, R0:16, R1:16
cfi      stackframe CFA SP DATA

; The virtual resource for the return address column.
cfi      virtualresource RET:16
cfi      endnames trivialNames

```

Defining the common block

The common block for the simple example above would be:

```

cfi      common trivialCommon using trivialNames
cfi      returnaddress RET DATA
cfi      CFA SP + 2
cfi      R0 undefined
cfi      R1 samevalue

; Offset -2 from top of frame.
cfi      RET frame(CFA, -2)
cfi      endcommon trivialCommon

```

Note: `SP` cannot be changed using a `CFI` directive as it is the resource associated with `CFA`.

Annotating your source code within a data block

You should place the `CFI` directives at the point where the call frame information has changed, in other words, immediately *after* the instruction that changes the call frame information.

Continuing the simple example, the data block would be:

```
                rseg    CODE:CODE
                cfi     block func1block using trivialCommon
                cfi     function func1

func1           push    r1
                cfi     CFA SP + 4
                cfi     R1 frame(CFA, -4)
                mov     r1, #4
                call   func2
                pop     r0
                cfi     R1 R0
                cfi     CFA SP + 2
                mov     r1, r0
                cfi     R1 samevalue
                ret
                cfi     endblock func1block
```


Assembler options

- Using command line assembler options
- Summary of assembler options
- Description of assembler options

Using command line assembler options

Assembler options are parameters you can specify to change the default behavior of the assembler. You can specify options from the command line—which is described in more detail in this section—and from within the IAR Embedded Workbench® IDE.



The IAR Project Management and Building Guide for 8051 describes how to set assembler options in the IDE, and gives reference information about the available options.

SPECIFYING OPTIONS AND THEIR PARAMETERS

To set assembler options from the command line, include them after the a8051 command:

```
a8051 [options] [sourcefile] [options]
```

These items must be separated by one or more spaces or tab characters.

If all the optional parameters are omitted, the assembler displays a list of available options a screenful at a time. Press Enter to display the next screenful.

For example, when assembling the source file `power2.s51`, use this command to generate a list file to the default filename (`power2.lst`):

```
a8051 power2.s51 -L
```

Some options accept a filename (that may be prefixed by a path), included after the option letter with a separating space. For example, to generate a list file with the name `list.lst`:

```
a8051 power2.s51 -l list.lst
```

Some other options accept a string that is not a filename. This is included after the option letter, but without a space. For example, to generate a list file to the default filename but in the subdirectory named `list`:

```
a8051 power2.s51 -Llist\
```

Note: The subdirectory you specify must already exist. The trailing backslash is required to separate the name of the subdirectory from the default filename.

EXTENDED COMMAND LINE FILE

In addition to accepting options and source filenames from the command line, the assembler can accept them from an extended command line file.

By default, extended command line files have the extension `.xcl`, and can be specified using the `-f` command line option. For example, to read the command line options from `extend.xcl`, enter:

```
a8051 -f extend.xcl
```

Summary of assembler options

This table summarizes the assembler options available from the command line:

Command line option	Description
<code>-B</code>	Macro execution information
<code>-c</code>	Conditional list
<code>-D</code>	Defines preprocessor symbols
<code>-E</code>	Maximum number of errors
<code>-f</code>	Extends the command line
<code>-G</code>	Opens standard input as source
<code>-g</code>	Disables the automatic search for system include files
<code>-I</code>	Adds a search path for a header file
<code>-i</code>	Lists <code>#included</code> text
<code>-L</code>	Generates a list file to path
<code>-l</code>	Generates a list file
<code>-M</code>	Macro quote characters
<code>-N</code>	Omits header from the assembler listing
<code>-n</code>	Enables support for multibyte characters
<code>--no_path_in_file_macros</code>	Removes the path from the return value of the symbols <code>__FILE__</code> and <code>__BASE_FILE__</code>
<code>-O</code>	Sets the object filename to path
<code>-o</code>	Sets the object filename

Table 12: Assembler options summary

Command line option	Description
-p	Sets the number of lines per page in the list file
-r	Generates debug information.
-S	Sets silent operation
-s	Case-sensitive user symbols
--system_include_dir	Specifies the path for system include files
-t	Tab spacing
-U	Undefines a symbol
-v	Processor configuration
-w	Disables warnings
-x	Includes cross-references

Table 12: Assembler options summary (Continued)

Description of assembler options

The following sections give detailed reference information about each assembler option.



Note that if you use the page **Extra Options** to specify specific command line options, the IDE does not perform an instant check for consistency problems like conflicting options, duplication of options, or use of irrelevant options.

-B

Syntax

-B

Description

Use this option to make the assembler print macro execution information to the standard output stream for every call to a macro. The information consists of:

- The name of the macro
- The definition of the macro
- The arguments to the macro
- The expanded text of the macro.

This option is mainly used in conjunction with the list file options `-L` or `-l`.

See also

`-L`, page 45.



Project>Options>Assembler >List>Macro execution info

-C

Syntax `-c {S | D | M | E | A | O}`

Parameters

S	No structured assembler list
D	Disables list file
M	Includes macro definitions
E	Excludes macro expansions
A	Includes assembled lines only
O	Includes multiline code

Description

Use this option to control the contents of the assembler list file. This option is mainly used in conjunction with the list file options `-L` or `-l`.

See also

`-L`, page 45.



To set related options, select:

Project>Options>Assembler>List

-D

Syntax `-Dsymbol [=value]`

Parameters

<i>symbol</i>	The name of the symbol you want to define.
<i>value</i>	The value of the symbol. If no value is specified, 1 is used.

Description

Use this option to define a symbol to be used by the preprocessor.

Example

You might want to arrange your source code to produce either the test version or the production version of your application, depending on whether the symbol `TESTVER` was defined. To do this, use include sections such as:

```
#ifndef TESTVER
... ; additional code lines for test version only
#endif
```

Then select the version required on the command line as follows:

```
Production version:  a8051 prog
Test version:       a8051 prog -DTESTVER
```

Alternatively, your source might use a variable that you must change often. You can then leave the variable undefined in the source, and use `-D` to specify the value on the command line; for example:

```
a8051 prog -DFRAMERATE=3
```



Project>Options>Assembler>Preprocessor>Defined symbols

-E

Syntax	<code>-E<i>number</i></code>	
Parameters	<i>number</i>	The number of errors before the assembler stops the assembly. <i>number</i> must be a positive integer; 0 indicates no limit.
Description	Use this option to specify the maximum number of errors that the assembler reports. By default, the maximum number is 100.	



Project>Options>Assembler>Diagnostics>Max number of errors

-f

Syntax	<code>-f <i>filename</i></code>	
Parameters	<i>filename</i>	The commands that you want to extend the command line with are read from the specified file. Notice that there must be a space between the option itself and the filename.
	For information about specifying a filename, see <i>Using command line assembler options</i> , page 39.	
Description	Use this option to extend the command line with text read from the specified file.	

The `-f` option is particularly useful if there are many options which are more conveniently placed in a file than on the command line itself.

Example

To run the assembler with further options taken from the file `extend.xcl`, use:

```
a8051 prog -f extend.xcl
```

See also

Extended command line file, page 40.



To set this option, use:

Project>Options>Assembler>Extra Options

-G**Syntax**

`-G`

Description

Use this option to make the assembler read the source from the standard input stream, rather than from a specified source file.

When `-G` is used, you cannot specify a source filename.



This option is not available in the IDE.

-g**Syntax**

`-g`

Description

By default, the assembler automatically locates the system include files. Use this option to disable the automatic search for system include files. In this case, you might need to set up the search path by using the `-I` assembler option.



Project>Options>Assembler>Preprocessor>Ignore standard include directories

-I**Syntax**

`-Ipath`

Parameters

path

The search path for `#include` files.

Description Use this option to specify paths to be used by the preprocessor. This option can be used more than once on the command line.

By default, the assembler searches for `#include` files in the current working directory, in the system header directories, and in the paths specified in the `A8051_INC` environment variable. The `-I` option allows you to give the assembler the names of directories which it will also search if it fails to find the file in the current working directory.

Example For example, using the options:

```
-Ic:\global\ -Ic:\thisproj\headers\
```

and then writing:

```
#include "asmlib.hdr"
```

in the source code, make the assembler search first in the current directory, then in the directory `c:\global\`, and then in the directory `C:\thisproj\headers\`. Finally, the assembler searches the directories specified in the `A8051_INC` environment variable, provided that this variable is set, and in the system header directories.



Project>Options>Assembler>Preprocessor>Additional include directories

-i

Syntax `-i`

Description Use this option to list `#include` files in the list file.

By default, the assembler does not list `#include` file lines because these often come from standard files and would waste space in the list file. The `-i` option allows you to list these file lines.



Project>Options>Assembler >List>#included text


-L

Syntax `-L[path]`


Parameters

No parameter

Generates a listing with the same name as the source file, but with the filename extension `lst`.

	<i>path</i>	The path to the destination of the list file. Note that you must not include a space before the path.
Description	By default, the assembler does not generate a list file. Use this option to make the assembler generate one and send it to the file <i>[path] sourcename.lst</i> . -L cannot be used at the same time as -l.	
Example	To send the list file to <code>list\prog.lst</code> rather than the default <code>prog.lst</code> : <code>a8051 prog -Llist\</code>	
		To set related options, select: Project>Options>Assembler >List

-l

Syntax	<code>-l filename</code>	
Parameters	<i>filename</i>	The output is stored in the specified file. Note that you must include a space before the filename. If no extension is specified, <code>lst</code> is used.
	For information about specifying a filename, see <i>Using command line assembler options</i> , page 39.	
Description	Use this option to make the assembler generate a listing and send it to the file <i>filename</i> . By default, the assembler does not generate a list file. To generate a list file with the default filename, use the -L option instead.	
		To set related options, select: Project>Options>Assembler >List

-M

Syntax	<code>-Mab</code>	
Parameters	<i>ab</i>	The characters to be used as left and right quotes of each macro argument, respectively.

Description Use this option to sets the characters to be used as left and right quotes of each macro argument to *a* and *b* respectively.

By default, the characters are `<` and `>`. The `-M` option allows you to change the quote characters to suit an alternative convention or simply to allow a macro argument to contain `<` or `>` themselves.

Example For example, using the option:

```
-M[]
```

in the source you would write, for example:

```
print [>]
```

to call a macro `print` with `>` as the argument.

Note: Depending on your host environment, it might be necessary to use quote marks with the macro quote characters, for example:

```
a8051 filename -M'<>'
```



Project>Options>Assembler >Language>Macro quote characters

-N

Syntax `-N`

Description Use this option to omit the header section that is printed by default in the beginning of the list file.

This option is useful in conjunction with the list file options `-L` or `-l`.

See also `-L`, page 45.



Project>Options>Assembler >List>Include header

-n

Syntax `-n`

Description By default, multibyte characters cannot be used in assembler source code. Use this option to interpret multibyte characters in the source code according to the host computer's default setting for multibyte support.

Multibyte characters are allowed in C/C++ style comments, in string literals, and in character constants. They are transferred untouched to the generated code.



Project>Options>Assembler >Language>Enable multibyte support

--no_path_in_file_macros

Syntax `--no_path_in_file_macros`

Description Use this option to exclude the path from the return value of the predefined preprocessor symbols `__FILE__` and `__BASE_FILE__`.



This option is not available in the IDE.

-O

Syntax `-O[path]`

Parameters

path The path to the destination of the object file. Note that you must not include a space before the path.

Description

Use this option to set the path to be used on the name of the object file.

By default, the path is null, so the object filename corresponds to the source filename. The `-O` option lets you specify a path, for example, to direct the object file to a subdirectory.

Note that `-O` cannot be used at the same time as `-o`.

Example

To send the object code to the file `obj\prog.r51` rather than to the default file `prog.r51`:

```
a8051 prog -Oobj\
```



Project>Options>General Options>Output>Output directories>Object files

-o

Syntax `-o {filename|directory}`

Parameters

<i>filename</i>	The object code is stored in the specified file.
<i>directory</i>	The object code is stored in a file (filename extension <code>o</code>) which is stored in the specified directory.

For information about specifying a filename or directory, see *Using command line assembler options*, page 39.

Description

By default, the object code produced by the assembler is located in a file with the same name as the source file, but with the extension `o`. Use this option to specify a different output filename for the object code.

The `-o` option cannot be used at the same time as the `-o` option.



Project>Options>General Options>Output>Output directories>Object files

-p

Syntax `-plines`

Parameters

<i>lines</i>	The number of lines per page, which must be in the range 10 to 150.
--------------	---

Description

Use this option to set the number of lines per page explicitly.

This option is used in conjunction with the list options `-L` or `-l`.

See also

`-L`, page 45

`-l`, page 46.



Project>Options>Assembler>List>Lines/page

-r

Syntax `-r`

Description Use this option to make the assembler generate debug information, which means the generated output can be used in a symbolic debugger such as IAR C-SPY® Debugger.



Project>Options>Assembler >Output>Generate debug information

-S

Syntax `-S`

Description By default, the assembler sends various minor messages via the standard output stream. Use this option to make the assembler operate without sending any messages to the standard output stream.

The assembler sends error and warning messages to the error output stream, so they are displayed regardless of this setting.



This option is not available in the IDE.

-s

Syntax `-s {+|-}`

Parameters

+ Case-sensitive user symbols.
- Case-insensitive user symbols.


Description Use this option to control whether the assembler is sensitive to the case of user symbols. By default, case sensitivity is on.

Example By default, for example LABEL and label refer to different symbols. When -s- is used, LABEL and label instead refer to the same symbol.



Project>Options>Assembler>Language>User symbols are case sensitive

--system_include_dir

Syntax	<code>--system_include_dir path</code>
Parameters	<i>path</i> The path to the system include files.
Description	By default, the assembler automatically locates the system include files. Use this option to explicitly specify a different path to the system include files. This might be useful if you have not installed IAR Embedded Workbench in the default location.
	 This option is not available in the IDE.

-t

Syntax	<code>-tn</code>
Parameters	<i>n</i> The tab spacing; must be in the range 2 to 9.
Description	By default, the assembler sets 8 character positions per tab stop. Use this option to specify a different tab spacing. This option is useful in conjunction with the list options <code>-L</code> or <code>-l</code> .
See also	<code>-L</code> , page 45 <code>-l</code> , page 46.

**Project>Options>Assembler>List>Tab spacing****-U**

Syntax	<code>-U<i>symbol</i></code>
Parameters	<i>symbol</i> The predefined symbol to be undefined.
Description	By default, the assembler provides certain predefined symbols.

Use this option to undefine such a predefined symbol to make its name available for your own use through a subsequent `-D` option or source definition.

Example

To use the name of the predefined symbol `__TIME__` for your own purposes, you could undefine it with:

```
a8051 prog -U__TIME__
```

See also

Predefined symbols, page 23.



This option is not available in the IDE.

-v**Syntax**

```
-v[0|1|2]
```

Parameters

0 (default)

Supports derivatives that use a standard 8051 core, with a maximum of 64 Kbytes of code memory. This option corresponds to the compiler option `--cpu=plain`.

1

Supports derivatives with a maximum of 2 Kbytes of code memory (80751). Using this processor option, no long jump (`LJMP`) instructions will be generated, only the shorter `AJMP` instructions. This option corresponds to the compiler option `--cpu=tiny`.

2

Supports derivatives that use cores similar to the extended core of the Dallas DS80C390/DS80C400 processors. Using this processor option, 3-byte addresses will be generated when appropriate. This option corresponds to the compiler option `--cpu=extended1`.

Description

Use this option to specify the processor configuration.



Project>Options>General Options>Target>CPU core

-w

Syntax `-w[+|-|+n|-n|+m-n|-m-n] [s]`

Parameters

No parameter	Disables all warnings.
+	Enables all warnings.
-	Disables all warnings.
+n	Enables just warning <i>n</i> .
-n	Disables just warning <i>n</i> .
+m-n	Enables warnings <i>m</i> to <i>n</i> .
-m-n	Disables warnings <i>m</i> to <i>n</i> .
s	Generates the exit code 1 if a warning message is produced. By default, warnings generate exit code 0.

Description

By default, the assembler displays a warning message when it detects an element of the source code which is legal in a syntactical sense, but might contain a programming error.

Use this option to disable all warnings, a single warning, or a range of warnings.

Note that the `-w` option can only be used once on the command line.

Example

To disable just warning 0 (unreferenced label), use this command:

```
a8051 prog -w-0
```

To disable warnings 0 to 8, use this command:

```
a8051 prog -w-0-8
```

See also

Assembler diagnostics, page 123.

To set related options, select:



Project>Options>Assembler>Diagnostics

-X

Syntax -x{D|I|2}

Parameters

D	Includes preprocessor #defines.
I	Includes internal symbols.
2	Includes dual-line spacing.

Description

Use this option to make the assembler include a cross-reference table at the end of the list file.

This option is useful in conjunction with the list options -L or -l.

See also

-L, page 45

-l, page 46.



Project>Options>Assembler>List>Include cross reference

UNARY OPERATORS

Precedence: 1

+	Unary plus.
-	Unary minus.
!, NOT	Logical NOT.
~, BITNOT	Bitwise NOT.
LOW	Low byte.
HIGH	High byte.
BYTE2	Second byte.
BYTE3	Third byte.
BYTE4	Fourth byte.
LWRD	Low word.
HWRD	High word.
DATE	Current time/date.
LOC	Local variable reference.
PRM	Parameter reference.
SFB	Segment begin.
SFE	Segment end.
SIZEOF	Segment size.

MULTIPLICATIVE ARITHMETIC OPERATORS

Precedence: 2

*	Multiplication.
/	Division.
%	Modulo.

ADDITIVE ARITHMETIC OPERATORS

Precedence: 3

+	Addition.
-	Subtraction.

SHIFT OPERATORS

Precedence: 4

>>, SHR	Logical shift right.
<<, SHL	Logical shift left.

AND OPERATORS

Precedence: 5

&&, AND	Logical AND.
&, BITAND	Bitwise AND.

OR OPERATORS

Precedence: 6

, OR	Logical OR.
, BITOR	Bitwise OR.
XOR	Logical exclusive OR.
^, BITXOR	Bitwise exclusive OR.

COMPARISON OPERATORS

Precedence: 7

=, ==, EQ	Equal.
<>, !=, NE	Not equal.
>, GT	Greater than.

<, LT	Less than.
UGT	Unsigned greater than.
ULT	Unsigned less than.
>=, GE	Greater than or equal.
<=, LE	Less than or equal.

Description of assembler operators

This section gives detailed descriptions of each assembler operator.

See also *Expressions, operands, and operators*, page 20.

() Parenthesis

Precedence	1
Description	(and) group expressions to be evaluated separately, overriding the default precedence order.
Example	1+2*3 -> 7 (1+2)*3 -> 9

* Multiplication

Precedence	2
Description	* produces the product of its two operands. The operands are taken as signed 32-bit integers and the result is also a signed 32-bit integer.
Example	2*2 -> 4 -2*2 -> -4

+ Unary plus

Precedence	1
Description	Unary plus operator; performs nothing.
Example	+3 -> 3 3*+2 -> 6

+ Addition

Precedence	3
Description	The + addition operator produces the sum of the two operands which surround it. The operands are taken as signed 32-bit integers and the result is also a signed 32-bit integer.
Example	92+19 -> 111 -2+2 -> 0 -2+-2 -> -4

- Unary minus

Precedence	1
Description	The unary minus operator performs arithmetic negation on its operand. The operand is interpreted as a 32-bit signed integer and the result of the operator is the two's complement negation of that integer.
Example	-3 -> -3 3*-2 -> -6 4--5 -> 9

- Subtraction

Precedence	3
Description	The subtraction operator produces the difference when the right operand is taken away from the left operand. The operands are taken as signed 32-bit integers and the result is also signed 32-bit integer.

Example

```
92-19 -> 73
-2-2 -> -4
-2--2 -> 0
```

/ Division

Precedence 2

Description / produces the integer quotient of the left operand divided by the right operator. The operands are taken as signed 32-bit integers and the result is also a signed 32-bit integer.

Example

```
9/2 -> 4
-12/3 -> -4
9/2*6 -> 24
```

< Less than

Precedence 7

Description < or LT evaluates to 1 (true) if the left operand has a lower numeric value than the right operand, otherwise it is 0 (false).

Example

```
-1 < 2 -> 1
2 < 1 -> 0
2 < 2 -> 0
```

<= Less than or equal

Precedence 7

Description <= or LE evaluates to 1 (true) if the left operand has a numeric value that is lower than or equal to the right operand, otherwise it is 0 (false).

Example

```
1 <= 2 -> 1
2 <= 1 -> 0
1 <= 1 -> 1
```

<>, != Not equal

Precedence	7
Description	<>, !=, or NE evaluates to 0 (false) if its two operands are identical in value or to 1 (true) if its two operands are not identical in value.
Example	<pre>1 <> 2 -> 1 2 <> 2 -> 0 'A' <> 'B' -> 1</pre>

=, == Equal

Precedence	7
Description	=, ==, or EQ evaluates to 1 (true) if its two operands are identical in value, or to 0 (false) if its two operands are not identical in value.
Example	<pre>1 = 2 -> 0 2 == 2 -> 1 'ABC' = 'ABCD' -> 0</pre>

> Greater than

Precedence	7
Description	> or GT evaluates to 1 (true) if the left operand has a higher numeric value than the right operand, otherwise it is 0 (false).
Example	<pre>-1 > 1 -> 0 2 > 1 -> 1 1 > 1 -> 0</pre>

>= Greater than or equal

Precedence	7
Description	<p>>= or GE evaluates to 1 (true) if the left operand is equal to or has a higher numeric value than the right operand, otherwise it is 0 (false).</p> <p>>= evaluates to 1 (true) if the left operand is equal to or has a higher numeric value than the right operand, otherwise it is 0 (false).</p>

Example 1010B | 0101B -> 1111B
 1010B | 0000B -> 1010B

^ Bitwise exclusive OR

Precedence 6

Description ^ or BITXOR performs bitwise XOR on its operands. Each bit in the 32-bit result is the exclusive OR of the corresponding bits in the operands.

Example 1010B ^ 0101B -> 1111B
 1010B ^ 0011B -> 1001B

% Modulo

Precedence 2

Description % produces the remainder from the integer division of the left operand by the right operand. The operands are taken as signed 32-bit integers and the result is also a signed 32-bit integer.

 X % Y is equivalent to X-Y*(X/Y) using integer division.

Example 2 % 2 -> 0
 12 % 7 -> 5
 3 % 2 -> 1

! Logical NOT

Precedence 1

Description ! or NOT negates a logical argument.

Example ! 0101B -> 0
 ! 0000B -> 1

|| Logical OR

Precedence	6
Description	or OR performs a logical OR between two integer operands.
Example	1010B 0000B -> 1 0000B 0000B -> 0

<< Logical shift left

Precedence	4
Description	<< or SHL shifts the left operand, which is always treated as <code>unsigned</code> , to the left. The number of bits to shift is specified by the right operand, interpreted as an integer value between 0 and 32.
Example	00011100B << 3 -> 11100000B 000001111111111111B << 5 -> 11111111111100000B 14 << 1 -> 28

>> Logical shift right

Precedence	4
Description	>> or SHR shifts the left operand, which is always treated as <code>unsigned</code> , to the right. The number of bits to shift is specified by the right operand, interpreted as an integer value between 0 and 32.
Example	01110000B >> 3 -> 00001110B 111111111111111111B >> 20 -> 0 14 >> 1 -> 7

BYTE2 Second byte

Precedence	1
Description	BYTE2 takes a single operand, which is interpreted as an unsigned 32-bit integer value. The result is the middle-low byte (bits 15 to 8) of the operand.
Example	BYTE2 0x12345678 -> 0x56

BYTE3 Third byte

Precedence	1
Description	<code>BYTE3</code> takes a single operand, which is interpreted as an unsigned 32-bit integer value. The result is the middle-high byte (bits 23 to 16) of the operand.
Example	<code>BYTE3 0x12345678 -> 0x34</code>

BYTE4 Fourth byte

Precedence	1
Description	<code>BYTE4</code> takes a single operand, which is interpreted as an unsigned 32-bit integer value. The result is the high byte (bits 31 to 24) of the operand.
Example	<code>BYTE4 0x12345678 -> 0x12</code>

DATE Current time/date

Precedence	1												
Description	<p><code>DATE</code> gets the time when the current assembly began.</p> <p>The <code>DATE</code> operator takes an absolute argument (expression) and returns:</p> <table> <tr> <td><code>DATE 1</code></td> <td>Current second (0–59).</td> </tr> <tr> <td><code>DATE 2</code></td> <td>Current minute (0–59).</td> </tr> <tr> <td><code>DATE 3</code></td> <td>Current hour (0–23).</td> </tr> <tr> <td><code>DATE 4</code></td> <td>Current day (1–31).</td> </tr> <tr> <td><code>DATE 5</code></td> <td>Current month (1–12).</td> </tr> <tr> <td><code>DATE 6</code></td> <td>Current year MOD 100 (1998 →98, 2000 →00, 2002 →02).</td> </tr> </table>	<code>DATE 1</code>	Current second (0–59).	<code>DATE 2</code>	Current minute (0–59).	<code>DATE 3</code>	Current hour (0–23).	<code>DATE 4</code>	Current day (1–31).	<code>DATE 5</code>	Current month (1–12).	<code>DATE 6</code>	Current year MOD 100 (1998 →98, 2000 →00, 2002 →02).
<code>DATE 1</code>	Current second (0–59).												
<code>DATE 2</code>	Current minute (0–59).												
<code>DATE 3</code>	Current hour (0–23).												
<code>DATE 4</code>	Current day (1–31).												
<code>DATE 5</code>	Current month (1–12).												
<code>DATE 6</code>	Current year MOD 100 (1998 →98, 2000 →00, 2002 →02).												
Example	<p>To specify the date of assembly:</p> <pre>today: DC8 DATE 5, DATE 4, DATE 3</pre>												

HIGH High byte

Precedence	1
Description	HIGH takes a single operand to its right which is interpreted as an unsigned, 16-bit integer value. The result is the unsigned 8-bit integer value of the higher order byte of the operand.
Example	HIGH 0xABCD -> 0xAB

HWRD High word

Precedence	1
Description	HWRD takes a single operand, which is interpreted as an unsigned, 32-bit integer value. The result is the high word (bits 31 to 16) of the operand.
Example	HWRD 0x12345678 -> 0x1234

LOC Local variable reference

Syntax	<i>LOC(function, segment, offset)</i>	
Precedence	1	
Parameters	<i>function</i>	The name of the function.
	<i>segment</i>	The name of a memory segment, which must be defined before LOC is used.
	<i>offset</i>	An offset from the start address.
Description	<p>LOC evaluates to an absolute address in the memory area block used for a function's local variables in a specific segment. This evaluation occurs at link time.</p> <p>LOC is intended for functions using static overlays. The memory area block for local variables must have been defined using the <code>LOCFRAME</code> assembler directive.</p> <p>See also the <i>IAR C/C++ Compiler User Guide for 8051</i> for information about the assembler language interface.</p>	

Example `MOV R0, #LOC (func, IOVERLAY, 0)`

This loads the address of the first local variable of `func` into the register `R0`. The `IOVERLAY` memory segment is used for storing static overlay frames.

LOW Low byte

Precedence 1

Description `LOW` takes a single operand, which is interpreted as an unsigned, 32-bit integer value. The result is the unsigned, 8-bit integer value of the lower order byte of the operand.

Example `LOW 0xABCD -> 0xCD`

LWRD Low word

Precedence 1

Description `LWRD` takes a single operand, which is interpreted as an unsigned, 32-bit integer value. The result is the low word (bits 15 to 0) of the operand.

Example `LWRD 0x12345678 -> 0x5678`

PRM Parameter reference

Syntax `PRM(function, segment, offset)`

Precedence 1

Parameters

<i>function</i>	The name of the function.
<i>segment</i>	The name of a memory segment, which must be defined before <code>PRM</code> is used.
<i>offset</i>	An offset from the start address.

Description `PRM` evaluates to an absolute address in the memory area block used for a function's parameters in a specific segment. This evaluation occurs at link time.

`PRM` is intended for functions using static overlays. The memory area block for parameters must have been defined using the `ARGFRAME` assembler directive.

See also the *IAR C/C++ Compiler User Guide for 8051* for information about the assembler language interface.

Example `MOV R0, #PRM(func, IOVERLAY, 0)`

This loads the address of the first parameter of `func` into the register `R0`. The `IOVERLAY` memory segment is used for storing static overlay frames.

SFB Segment begin

Syntax `SFB(segment [{+|-} offset])`

Precedence 1

Parameters

segment The name of a relocatable segment, which must be defined before `SFB` is used.

offset An optional offset from the start address. The parentheses are optional if *offset* is omitted.

Description `SFB` accepts a single operand to its right. The operator evaluates to the absolute address of the first byte of that segment. This evaluation occurs at linking time.

Example

```

name      demo
rseg      MYCODE
start:    dc16    sfb(MYCODE)

```

Even if this code is linked with many other modules, `start` is still set to the address of the first byte of the segment.

SFE Segment end

Syntax `SFE(segment [{+|-} offset])`

Precedence 1

Parameters

segment The name of a relocatable segment, which must be defined before `SFE` is used.

offset An optional offset from the start address. The parentheses are optional if *offset* is omitted.

Description `SFE` accepts a single operand to its right. The operator evaluates to the address of the first byte after the segment end. This evaluation occurs at linking time.

Example

```

                                name    demo
                                rseg    MYCODE
end:                             dc16   sfe (MYCODE)

```

Even if this code is linked with many other modules, `end` is still set to the first byte after the segment `MYCODE`.

The size of the segment `MYCODE` can be achieved by using the `SIZEOF` operator or calculated as:

```
SFE (MYCODE) - SFB (MYCODE)
```

SIZEOF Segment size

Syntax `SIZEOF segment`

Precedence 1

Parameters

`segment` The name of a relocatable segment, which must be defined before `SIZEOF` is used.

Description `SIZEOF` generates `SFE-SFB` for its argument. That is, it calculates the size in bytes of a segment. This is done when modules are linked together.

Example This code sets `size` to the size of the segment `MYCODE`:

```

                                name    demo
                                rseg    MYCODE
size:                             dc16   sizeof MYCODE

```

UGT Unsigned greater than

Precedence 7

Description `UGT` evaluates to 1 (true) if the left operand has a larger value than the right operand, otherwise it is 0 (false). The operation treats the operands as unsigned values.

Example

```

2 UGT 1 -> 1
-1 UGT 1 -> 1

```

ULT Unsigned less than

Precedence	7
Description	ULT evaluates to 1 (true) if the left operand has a smaller value than the right operand, otherwise it is 0 (false). The operation treats the operands as unsigned values.
Example	1 ULT 2 -> 1 -1 ULT 2 -> 0

XOR Logical exclusive OR

Precedence	6
Description	XOR evaluates to 1 (true) if either the left operand or the right operand is non-zero, but to 0 (false) if both operands are zero or both are non-zero. Use XOR to perform logical XOR on its two operands.
Example	0101B XOR 1010B -> 0 0101B XOR 0000B -> 1

Assembler directives

This chapter gives a summary of the assembler directives and provides detailed reference information for each category of directives.

Summary of assembler directives

The assembler directives are classified into these groups according to their function:

- *Module control directives*, page 75
- *Symbol control directives*, page 79
- *Segment control directives*, page 81
- *Value assignment directives*, page 86
- *Conditional assembly directives*, page 90
- *Macro processing directives*, page 91
- *Listing control directives*, page 99
- *C-style preprocessor directives*, page 104
- *Data definition or allocation directives*, page 108
- *Assembler control directives*, page 110
- *Function directives*, page 113
- *Call frame information directives for names blocks*, page 114.
- *Call frame information directives for common blocks*, page 116
- *Call frame information directives for data blocks*, page 117
- *Call frame information directives for tracking resources and CFAs*, page 118

This table gives a summary of all the assembler directives:

Directive	Description	Section
<code>_args</code>	Is set to number of arguments passed to macro.	Macro processing
<code>\$</code>	Includes a file.	Assembler control
<code>#define</code>	Assigns a value to a label.	C-style preprocessor
<code>#elif</code>	Introduces a new condition in an <code>#if...#endif</code> block.	C-style preprocessor
<code>#else</code>	Assembles instructions if a condition is false.	C-style preprocessor
<code>#endif</code>	Ends an <code>#if</code> , <code>#ifdef</code> , or <code>#ifndef</code> block.	C-style preprocessor

Table 13: Assembler directives summary

Directive	Description	Section
<code>#error</code>	Generates an error.	C-style preprocessor
<code>#if</code>	Assembles instructions if a condition is true.	C-style preprocessor
<code>#ifdef</code>	Assembles instructions if a symbol is defined.	C-style preprocessor
<code>#ifndef</code>	Assembles instructions if a symbol is undefined.	C-style preprocessor
<code>#include</code>	Includes a file.	C-style preprocessor
<code>#line</code>	Changes the line numbers.	C-style preprocessor
<code>#message</code>	Generates a message on standard output.	C-style preprocessor
<code>#pragma</code>	Recognized but ignored.	C-style preprocessor
<code>#undef</code>	Undefines a label.	C-style preprocessor
<code>/*comment*/</code>	C-style comment delimiter.	Assembler control
<code>//</code>	C++ style comment delimiter.	Assembler control
<code>=</code>	Assigns a permanent value local to a module.	Value assignment
<code>ALIAS</code>	Assigns a permanent value local to a module.	Value assignment
<code>ALIGN</code>	Aligns the program location counter by inserting zero-filled bytes.	Segment control
<code>ALIGNRAM</code>	Aligns the program location counter.	Segment control
<code>ARGFRAME</code>	Declares the space used for the arguments to a function.	Function
<code>ASEG</code>	Begins an absolute segment.	Segment control
<code>ASEGN</code>	Begins a named absolute segment.	Segment control
<code>ASSIGN</code>	Assigns a temporary value.	Value assignment
<code>BLOCK</code>	Specifies the block number for an alias created by the <code>SYMBOL</code> directive.	Symbol control
<code>CASEOFF</code>	Disables case sensitivity.	Assembler control
<code>CASEON</code>	Enables case sensitivity.	Assembler control
<code>CFI</code>	Specifies call frame information.	Call frame information
<code>COL</code>	Sets the number of columns per page. Retained for backward compatibility reasons; recognized but ignored.	Listing control
<code>COMMON</code>	Begins a common segment.	Segment control
<code>DB</code>	Generates 8-bit constants, including strings.	Data definition or allocation

Table 13: Assembler directives summary (Continued)

Directive	Description	Section
DC8	Generates 8-bit constants, including strings.	Data definition or allocation
DC16	Generates 16-bit constants.	Data definition or allocation
DC24	Generates 24-bit constants.	Data definition or allocation
DC32	Generates 32-bit constants.	Data definition or allocation
DD	Generates 32-bit constants.	Data definition or allocation
DEFINE	Defines a file-wide value.	Value assignment
DS	Allocates space for 8-bit integers.	Data definition or allocation
DS8	Allocates space for 8-bit integers.	Data definition or allocation
DS16	Allocates space for 16-bit integers.	Data definition or allocation
DS24	Allocates space for 24-bit integers.	Data definition or allocation
DS32	Allocates space for 32-bit integers.	Data definition or allocation
DT	Generates 24-bit constants.	Data definition or allocation
DW	Generates 16-bit constants, including strings.	Data definition or allocation
ELSE	Assembles instructions if a condition is false.	Conditional assembly
ELSEIF	Specifies a new condition in an IF...ENDIF block.	Conditional assembly
END	Ends the assembly of the last module in a file.	Module control
ENDIF	Ends an IF block.	Conditional assembly
ENDM	Ends a macro definition.	Macro processing
ENDMAC	Ends a macro definition.	Macro processing
ENDMOD	Ends the assembly of the current module.	Module control

Table 13: Assembler directives summary (Continued)

Directive	Description	Section
ENDR	Ends a repeat structure.	Macro processing
EQU	Assigns a permanent value local to a module.	Value assignment
EVEN	Aligns the program counter to an even address.	Segment control
EXITM	Exits prematurely from a macro.	Macro processing
EXTERN	Imports an external symbol.	Symbol control
FUNCALL	Declares that the function <i>caller</i> calls the function <i>callee</i> .	Function
FUNCTION	Declares a label name to be a function.	Function
IF	Assembles instructions if a condition is true.	Conditional assembly
IMPORT	Imports an external symbol.	Symbol control
LIBRARY	Begins a library module.	Module control
LIMIT	Checks a value against limits.	Value assignment
LOCAL	Creates symbols local to a macro.	Macro processing
LOCFRAME	Declares the space used for the locals in a function.	Function
LSTCND	Controls conditional assembler listing.	Listing control
LSTCOD	Controls multi-line code listing.	Listing control
LSTEXP	Controls the listing of macro generated lines.	Listing control
LSTMAC	Controls the listing of macro definitions.	Listing control
LSTOUT	Controls assembler-listing output.	Listing control
LSTPAG	Retained for backward compatibility reasons. Recognized but ignored.	Listing control
LSTREP	Controls the listing of lines generated by repeat directives.	Listing control
LSTSAS	Controls structured assembler listing.	Listing control
LSTXRF	Generates a cross-reference table.	Listing control
MACRO	Defines a macro.	Macro processing
MODULE	Begins a library module.	Module control
NAME	Begins a program module.	Module control
ODD	Aligns the program location counter to an odd address.	Segment control
ORG	Sets the program location counter.	Segment control

Table 13: Assembler directives summary (Continued)

Directive	Description	Section
OVERLAY	Recognized but ignored.	Symbol control
PAGE	Retained for backward compatibility reasons.	Listing control
PAGSIZ	Retained for backward compatibility reasons.	Listing control
PROGRAM	Begins a program module.	Module control
PUBLIC	Exports symbols to other modules.	Symbol control
PUBWEAK	Exports symbols to other modules, multiple definitions allowed.	Symbol control
RADIX	Sets the default base.	Assembler control
REPT	Assembles instructions a specified number of times.	Macro processing
REPTC	Repeats and substitutes characters.	Macro processing
REPTI	Repeats and substitutes strings.	Macro processing
REQUIRE	Repeats subsequent instructions until a condition is true.	Symbol control
RSEG	Begins a relocatable segment.	Segment control
RTMODEL	Declares runtime model attributes.	Module control
SET	Assigns a temporary value.	Value assignment
SFRTYPE	Specifies SFR attributes.	Value assignment
STACK	Begins a stack segment.	Segment control
SYMBOL	Creates an alias that can be used for referring to a C/C++ symbol.	Symbol control

Table 13: Assembler directives summary (Continued)

Description of assembler directives

The following pages give reference information about the assembler directives.

Module control directives

Syntax	END [<i>address</i>]
	ENDMOD [<i>address</i>]
	LIBRARY <i>symbol</i> [(<i>expr</i>)]
	MODULE <i>symbol</i> [(<i>expr</i>)]
	NAME <i>symbol</i> [(<i>expr</i>)]

```
PROGRAM symbol [(expr)]
```

```
RTMODEL key, value
```

Parameters

<i>address</i>	An expression (label plus offset) that can be resolved at assembly time. It is output in the object code as a program entry address.
<i>expr</i>	An optional expression used by the assembler to encode the runtime options. It must be within the range 0-255 and evaluate to a constant value. The expression is only meaningful if you are assembling source code that originates as assembler output from the compiler.
<i>key</i>	A text string specifying the key.
<i>symbol</i>	Name assigned to module, used by XLINK, XAR, and XLIB when processing object files.
<i>value</i>	A text string specifying the value.

Description

Module control directives are used for marking the beginning and end of source program modules, and for assigning names and types to them. For information about the restrictions that apply when using a directive in an expression, see *Expression restrictions*, page 25.

Directive	Description	Expression restrictions
END	Ends the assembly of the last module in a file.	Locally defined symbols plus offset or integer constants
ENDMOD	Ends the assembly of the current module.	Locally defined symbols plus offset or integer constants
LIBRARY	Begins a library module.	No external references Absolute
MODULE	Begins a library module.	No external references Absolute
NAME	Begins a program module.	Absolute
PROGRAM	Begins a program module.	No external references Absolute
RTMODEL	Declares runtime model attributes.	Not applicable

Table 14: Module control directives

Beginning a program module

Use `NAME` or `PROGRAM` to begin a program module, and to assign a name for future reference by the IAR XLINK Linker, the IAR XAR Library Builder, and the IAR XLIB Librarian.

Program modules are unconditionally linked by XLINK, even if other modules do not reference them.

Beginning a library module

Use `MODULE` or `LIBRARY` to create libraries containing several small modules—like runtime systems for high-level languages—where each module often represents a single routine. With the multi-module facility, you can significantly reduce the number of source and object files needed.

Library modules are only copied into the linked code if other modules reference a public symbol in the module.

Beginning a module

Use any of the directives `NAME` or `PROGRAM` to begin an ELF module, and to assign a name.

A module is included in the linked application, even if other modules do not reference them. For more information about how modules are included in the linked application, read about the linking process in the *IAR C/C++ Compiler User Guide for 8051*.

Note: There can be only one module in a file.

Terminating a module

Use `ENDMOD` to define the end of a module.

Terminating the source file

Use `END` to indicate the end of the source file. Any lines after the `END` directive are ignored. The `END` directive also ends the last module in the file, if this is not done explicitly with an `ENDMOD` directive.

Defining a program entry

Program entries must be either relocatable or absolute and cannot be external. The defined program entry for the application will show up in the XLINK map file, and in some of the XLINK output formats.

Assembling multi-module files

These rules apply when assembling multi-module files:

- At the beginning of a new module all user symbols are deleted, except for those created by `DEFINE`, `#define`, or `MACRO`, the location counters are cleared, and the mode is set to absolute.
- Listing control directives remain in effect throughout the assembly.

Note: `END` must always be placed after the last module, and there must not be any source lines (except for comments and listing control directives) between an `ENDMOD` and the next module (beginning with `MODULE`, `LIBRARY`, `NAME`, or `PROGRAM`).

If any of the directives `NAME`, `MODULE`, `LIBRARY`, or `PROGRAM` is missing, the module is assigned the name of the source file and the attribute `program`.

Declaring runtime model attributes

Use `RTMODEL` to enforce consistency between modules. All modules that are linked together and define the same runtime attribute key must have the same value for the corresponding key value, or the special value `*`. Using the special value `*` is equivalent to not defining the attribute at all. It can however be useful to explicitly state that the module can handle any runtime model.

A module can have several runtime model definitions.

Note: The compiler runtime model attributes start with double underscores. In order to avoid confusion, this style must not be used in the user-defined assembler attributes.

If you are writing assembler routines for use with C or C++ code, and you want to control the module consistency, refer to the *IAR C/C++ Compiler User Guide for 8051*.

The following example defines three modules where:

- `MOD_1` and `MOD_2` cannot be linked together since they have different values for runtime model `CAN`.
- `MOD_1` and `MOD_3` can be linked together since they have the same definition of runtime model `RTOS` and no conflict in the definition of `CAN`.
- `MOD_2` and `MOD_3` can be linked together since they have no runtime model conflicts. The value `*` matches any runtime model value.

```

module mod_1
rtmodel "CAN",      "ISO11519"
rtmodel "Platform", "M7"
; ...
endmod

```

```

module mod_2
rtmodel "CAN", "ISO11898"
rtmodel "Platform", "*"
; ...
endmod

module mod_3
rtmodel "Platform", "M7"
; ...
end

```

Symbol control directives

Syntax

```

label BLOCK old_label, block_number

EXTERN symbol [,symbol] ...

IMPORT symbol [,symbol] ...

PUBLIC symbol [,symbol] ...

PUBWEAK symbol [,symbol] ...

REQUIRE symbol

label SYMBOL "C/C++_symbol" [,old_label]

```

Parameters

<i>block_number</i>	Block number of the alias created by the SYMBOL directive.
<i>C/C++_symbol</i>	C/C++ symbol to create an alias for.
<i>label</i>	Label to be used as an alias for a C/C++ symbol.
<i>old_label</i>	Alias created earlier by a SYMBOL directive.
<i>symbol</i>	Symbol to be imported or exported.

Description

These directives control how symbols are shared between modules:

Directive	Description
BLOCK	Specifies the block number for an alias created by the SYMBOL directive.
EXTERN, IMPORT	Imports an external symbol.
OVERLAY	Recognized but ignored.

Table 15: Symbol control directives

Directive	Description
PUBLIC	Exports symbols to other modules.
PUBWEAK	Exports symbols to other modules, multiple definitions allowed.
REQUIRE	Forces a symbol to be referenced.
SYMBOL	Creates an alias for a C/C++ symbol.

Table 15: Symbol control directives (Continued)

Exporting symbols to other modules

Use `PUBLIC` to make one or more symbols available to other modules. Symbols defined `PUBLIC` can be relocatable or absolute, and can also be used in expressions (with the same rules as for other symbols).

The `PUBLIC` directive always exports full 32-bit values, which makes it feasible to use global 32-bit constants also in assemblers for 8-bit and 16-bit processors. With the `LOW`, `HIGH`, `>>`, and `<<` operators, any part of such a constant can be loaded in an 8-bit or 16-bit register or word.

There can be any number of `PUBLIC`-defined symbols in a module.

Exporting symbols with multiple definitions to other modules

`PUBWEAK` is similar to `PUBLIC` except that it allows the same symbol to be defined in more than one module. Only one of those definitions is used by `XLINK`. If a module containing a `PUBLIC` definition of a symbol is linked with one or more modules containing `PUBWEAK` definitions of the same symbol, `XLINK` uses the `PUBLIC` definition.

A symbol defined as `PUBWEAK` must be a label in a segment part, and it must be the *only* symbol defined as `PUBLIC` or `PUBWEAK` in that segment part.

Note: Library modules are only linked if a reference to a symbol in that module is made, and that symbol was not already linked. During the module selection phase, no distinction is made between `PUBLIC` and `PUBWEAK` definitions. This means that to ensure that the module containing the `PUBLIC` definition is selected, you should link it before the other modules, or make sure that a reference is made to some other `PUBLIC` symbol in that module.

Importing symbols

Use `EXTERN` or `IMPORT` to import an untyped external symbol.

The `REQUIRE` directive marks a symbol as referenced. This is useful if the segment part containing the symbol must be loaded even if the code is not referenced.

Referring to scoped C/C++ symbols

Use the `SYMBOL` directive to create an alias for a C/C++ symbol. You can use the alias to refer to the C/C++ symbol. The symbol and the alias must be located within the same scope.

Use the `BLOCK` directive to provide the block scope for the alias.

Typically, the `SYMBOL` and the `BLOCK` directives are for compiler internal use only, for example, when referring to objects inside classes or namespaces. For detailed information about how to use these directives, declare and define your C/C++ symbol, compile, and view the assembler list file output.

Example

The following example defines a subroutine to print an error message, and exports the entry address `err` so that it can be called from other modules.

Because the message is enclosed in double quotes, the string will be followed by a zero byte.

It defines `print` as an external routine; the address is resolved at link time.

```

                name    errorMessage
                extern  print
                public  err

err            call    print
                db      "*** Error ***"
                ret

                end    err

```

Segment control directives

Syntax

```

ALIGN align [, value]

ALIGNRAM align

ASEG [start]

ASEGN segment [:type] [:flag] [, address]

COMMON segment [:type] [:flag] [(align)]

EVEN [value]

ODD [value]

ORG expr

RSEG segment [:type] [:flag] [(align)]

```

```
STACK segment [:type] [:flag] [(align)]
```

Parameters

<i>address</i>	Address where this segment part is placed.
<i>align</i>	The power of two to which the address should be aligned. The permitted range is 0 to 8. The default align value is 0.
<i>expr</i>	Address to set the location counter to.
<i>flag</i>	<p>ROOT, NOROOT</p> <p>ROOT (the default mode) indicates that the segment part must not be discarded.</p> <p>NOROOT means that the segment part is discarded by the linker if no symbols in this segment part are referred to. Normally, all segment parts except startup code and interrupt vectors should set this flag.</p> <p>REORDER, NOREORDER</p> <p>NOREORDER (the default mode) indicates that the segment parts must remain in order.</p> <p>REORDER allows the linker to reorder segment parts. For a given segment, all segment parts must specify the same state for this flag.</p> <p>SORT, NOSORT</p> <p>NOSORT (the default mode) indicates that the segment parts are not sorted.</p> <p>SORT means that the linker sorts the segment parts in decreasing alignment order. For a given segment, all segment parts must specify the same state for this flag.</p>
<i>segment</i>	The name of the segment. The segment name is a user-defined symbol that follows the rules described in <i>Symbols</i> , page 22.
<i>start</i>	A start address that has the same effect as using an <code>ORG</code> directive at the beginning of the absolute segment.
<i>type</i>	The memory type, typically <code>CODE</code> or <code>DATA</code> . In addition, any of the types supported by the IAR XLINK Linker.
<i>value</i>	Byte value used for padding, default is zero.

Description

The segment directives control how code and data are located. For information about the restrictions that apply when using a directive in an expression, see *Expression restrictions*, page 25.

Directive	Description	Expression restrictions
ALIGN	Aligns the program location counter by inserting zero-filled bytes.	No external references Absolute
ALIGNRAM	Aligns the program location counter.	No external references Absolute
ASEG	Begins an absolute segment.	No external references Absolute
ASEGN	Begins a named absolute segment.	No external references Absolute
COMMON	Begins a common segment.	No external references Absolute
EVEN	Aligns the program counter to an even address.	No external references Absolute
ODD	Aligns the program counter to an odd address.	No external references Absolute
ORG	Sets the program location counter (PLC).	No external references Absolute (see below)
RSEG	Begins a relocatable segment.	No external references Absolute
STACK	Begins a stack segment.	

Table 16: Segment control directives

Beginning an absolute segment

Use `ASEG` to set the absolute mode of assembly, which is the default at the beginning of a module.

If the parameter is omitted, the start address of the first segment is 0, and subsequent segments continue after the last address of the previous segment.

This example assembles interrupt routine entry addresses in the appropriate 8051 interrupt vectors using an absolute segment

```
extern      iesrv,t0srv

          aseg
          org      0
          jmp      main      ; Power on

          org      3
          jmp      iesrv     ; External interrupt

          org      0BH
          jmp      t0srv     ; Timer interrupt

main:     org      30H
          mov      A,#1

          end
```

Beginning a named absolute segment

Use `ASEGN` to start a named absolute segment located at the address *address*.

This directive has the advantage of allowing you to specify the memory type of the segment.

Beginning a relocatable segment

Use `RSEG` to start a new segment. The assembler maintains separate location counters (initially set to zero) for all segments, which makes it possible to switch segments and mode anytime without having to save the current program location counter.

Up to 65536 unique, relocatable segments can be defined in a single module.

In the following example, the data following the first `RSEG` directive is placed in a relocatable segment called `TABLE`; the `ORG` directive creates a gap of six bytes in the table.

The code following the second `RSEG` directive is placed in a relocatable segment called `CODE`:

```
extern  divrtn,mulrtn

rseg   TABLE
dw     divrtn,mulrtn

org    $+6
dw     subrtn
```

```

                                rseg    CODE
subrtn                          mov     A, R7
                                subb   A, #20
                                mov     R7, A
                                end

```

Beginning a common segment

Use `COMMON` to place data in memory at the same location as `COMMON` segments from other modules that have the same name. In other words, all `COMMON` segments of the same name start at the same location in memory and overlay each other.

Obviously, the `COMMON` segment type should not be used for overlaid executable code. A typical application would be when you want several different routines to share a reusable, common area of memory for data.

It can be practical to have the interrupt vector table in a `COMMON` segment, thereby allowing access from several routines.

The final size of the `COMMON` segment is determined by the size of largest occurrence of this segment. The location in memory is determined by the `XLINK -Z` command; see the IAR Linker and Library Tools Reference Guide.

Use the `align` parameter in any of the above directives to align the segment start address.

This example defines two common segments containing variables:

```

                                name    common1
                                common  MYDATA
count                          dd      1
                                endmod

                                name    common2
                                common  MYDATA
up                              db      1
                                org     $+2
down                            db      1
                                end

```

Because the common segments have the same name, `MYDATA`, the variables `up` and `count` refer to the same location in memory.

Setting the program location counter (PLC)

Use `ORG` to set the program location counter of the current segment to the value of an expression. When `ORG` is used in an absolute segment (`ASEG`), the parameter expression must be absolute. However, when `ORG` is used in a relative segment (`RSEG`), the

expression can be either absolute or relative (and the value is interpreted as an offset relative to the segment start in both cases).

The program location counter is set to zero at the beginning of an assembler module.

Aligning a segment

Use `ALIGN` to align the program location counter to a specified address boundary. You do this by specifying an expression for the power of two to which the program counter should be aligned. That is, a value of 1 aligns to an even address and a value of 2 aligns to an address evenly divisible by 4.

The alignment is made relative to the segment start; normally this means that the segment alignment must be at least as large as that of the alignment directive to give the desired result.

`ALIGN` aligns by inserting zero/filled bytes, up to a maximum of 255. The `EVEN` directive aligns the program counter to an even address (which is equivalent to `ALIGN 1`) and the `ODD` directive aligns the program location counter to an odd address. The value used for padding bytes must be within the range 0 to 255.

Use `ALIGNRAM` to align the program location counter by incrementing it; no data is generated. The parameter `align` can be within the range 0 to 30.

This example starts a relocatable segment, moves to an even address, and adds some data. It then aligns to a 64-byte boundary before creating a 64-byte table.

```

                                name    alignment
                                rseg    DATA      ; Start a relocatable data segment.
                                even    ; Ensure it is on an even boundary.
target    dc16    1              ; target and best will be on an
best      dc16    1              ; even boundary.
                                align    6          ; Now, align to a 64-byte boundary,
results   ds8     64             ; and create a 64-byte table.
                                end

```

Value assignment directives

Syntax

```

label = expr
label ALIAS expr
label ASSIGN expr
label DEFINE const_expr
label EQU expr
LIMIT expr, min, max, message

```

```
[const] SFRTYPE register attribute [,attribute] = value
label SET expr
```

Parameters

<i>attribute</i>	One or more of these: BYTE: The SFR must be accessed as a byte. READ: You can read from this SFR. WORD: The SFR must be accessed as a word. WRITE: You can write to this SFR.
<i>const_expr</i>	Constant value assigned to symbol.
<i>expr</i>	Value assigned to symbol or value to be tested.
<i>label</i>	Symbol to be defined.
<i>message</i>	A text message that is printed when <i>expr</i> is out of range.
<i>min, max</i>	The minimum and maximum values allowed for <i>expr</i> .
<i>register</i>	The special function register.
<i>value</i>	The SFR port address.

Description

These directives are used for assigning values to symbols:

Directive	Description
=, EQU	Assigns a permanent value local to a module.
ALIAS	Assigns a permanent value local to a module.
ASSIGN, SET	Assigns a temporary value.
DEFINE	Defines a file-wide value.
LIMIT	Checks a value against limits.
SFRTYPE	Specifies SFR attributes.

Table 17: Value assignment directives

Defining a temporary value

Use `ASSIGN` or `SET` to define a symbol that might be redefined, such as for use with macro variables. Symbols defined with `ASSIGN` or `SET` cannot be declared `PUBLIC`.

This example uses `SET` to redefine the symbol `cons` in a loop to generate a table of the first 8 powers of 3:

```

                                name    table
cons                            set     1

; Generate table of powers of 3.
cr_tabl    macro    times
                                dc32   cons
cons       set     cons * 3
                                if     times > 1
                                cr_tabl times - 1
                                endif
                                endm

                                rseg    CODE:CODE
table     cr_tabl 4
                                end

```

Defining a permanent local value

Use `EQU` or `=` to create a local symbol that denotes a number or offset. The symbol is only valid in the module in which it was defined, but can be made available to other modules with a `PUBLIC` directive (but not with a `PUBWEAK` directive).

Use `EXTERN` to import symbols from other modules.

Defining a permanent global value

Use `DEFINE` to define symbols that should be known to the module containing the directive and all modules following that module in the same source file. If a `DEFINE` directive is placed outside of a module, the symbol will be known to all modules following the directive in the same source file.

A symbol which was given a value with `DEFINE` can be made available to modules in other files with the `PUBLIC` directive.

Symbols defined with `DEFINE` cannot be redefined within the same file. Also, the expression assigned to the defined symbol must be constant.

Using local and global symbols

In the following example the symbol `value` defined in module `add1` is local to that module; a distinct symbol of the same name is defined in module `add2`. The `DEFINE` directive is used for declaring `locn` for use anywhere in the file:

```

name      add1
locn      define  020H          ; Definition of a permanent
                                ; global value.
value     equ     77           ; Definition of a local value.

mov       R1,locn
mov       A,value
add       A,R1
mov       R1,A
ret
endmod

name      add2
value     public add20
equ       77                 ; Redefinition of local value.

mov       R1,locn
mov       A,value
add       A,R1
mov       R1,A
ret
end

```

The symbol `locn` defined in module `add1` is also available to module `add2`.

Defining special function registers

Use `SFRTYPE` to create special function register labels with specified attributes.

In this example two SFR variables are declared with a variety of access capabilities:

```

name      sfrs
rseg      MYCODE

sfrtype  portb write, byte = 0x18 ; Byte write only
                                                ; access.
sfrtype  portd read,  byte = 0x12 ; Byte read only
                                                ; access.
mov       A,portb                       ; Illegal access.
end

```

Checking symbol values

Use `LIMIT` to check that expressions lie within a specified range. If the expression is assigned a value outside the range, an error message appears.

The check occurs as soon as the expression is resolved, which is during linking if the expression contains external references. The `min` and `max` expressions cannot involve references to forward or external labels, that is they must be resolved when encountered.

The following example sets the value of a variable called `speed` and then checks it, at assembly time, to see if it is in the range 10 to 30. This might be useful if `speed` is often changed at compile time, but values outside a defined range would cause undesirable behavior.

```

speed      module    setLimit
           set       23
           limit    speed,10,30,"Speed is out of range!"
           end

```

Conditional assembly directives

Syntax

```

ELSE
ELSEIF condition
ENDIF
IF condition

```

Parameters

<i>condition</i>	One of these:	
An absolute expression		The expression must not contain forward or external references, and any non-zero value is considered as true.
<i>string1=string2</i>		The condition is true if <i>string1</i> and <i>string2</i> have the same length and contents.
<i>string1<>string2</i>		The condition is true if <i>string1</i> and <i>string2</i> have different length or contents.

Description

Use the `IF`, `ELSE`, `ELSEIF`, and `ENDIF` directives to control the assembly process at assembly time. If the condition following the `IF` directive is not true, the subsequent

instructions do not generate any code (that is, it is not assembled or syntax checked) until an `ELSEIF` condition is true or `ELSE` or `ENDIF` directive is found.

Use `ELSEIF` to introduce a new condition after an `IF` directive. Conditional assembly directives can be used anywhere in an assembly, but have their greatest use in conjunction with macro processing.

All assembler directives (except for `END`) as well as the inclusion of files can be disabled by the conditional directives. Each `IF` directive must be terminated by an `ENDIF` directive. The `ELSE` and `ELSEIF` directives are optional, and if used, they must be inside an `IF...ENDIF` block. `IF...ENDIF` and `IF...ELSE...ENDIF` blocks can be nested to any level.

Example

This example uses a macro to subtract a constant from the register `r`:

```
sub      macro   r,c
          if     c = 1
            dec  r
          elseif c = 2
            dec  r
            dec  r
          else
            xch  A,r
            sub  A,#c
            xch  A,r
          endif
        endm
```

If the argument to the macro is less than 2, it generates `DEC` instructions to save instruction cycles and code size; otherwise it generates a `SUBB` instruction.

It could be tested with the following program:

```
main     mov     R6,#7
          sub     R6,2
          mov     R7,#22
          sub     R7,1
          ret
          end
```

Macro processing directives

Syntax	<code>_args</code>
	<code>ENDM</code>
	<code>ENDMAC</code>

```

ENDR

EXITM

LOCAL symbol [,symbol] ...

name MACRO [argument] [,argument] ...

REPT expr

REPTC formal,actual

REPTI formal,actual [,actual] ...

```

Parameters

<i>actual</i>	Strings to be substituted.
<i>argument</i>	Symbolic argument names.
<i>expr</i>	An expression.
<i>formal</i>	An argument into which each character of <i>actual</i> (REPTC) or each string of <i>actual</i> (REPTI) is substituted.
<i>name</i>	The name of the macro.
<i>symbol</i>	Symbols to be local to the macro.

Description

These directives allow user macros to be defined. For information about the restrictions that apply when using a directive in an expression, see *Expression restrictions*, page 25.

Directive	Description	Expression restrictions
<code>_args</code>	Is set to number of arguments passed to macro.	
ENDM	Ends a macro definition.	
ENDR	Ends a repeat structure.	
EXITM	Exits prematurely from a macro.	
LOCAL	Creates symbols local to a macro.	
MACRO	Defines a macro.	
REPT	Assembles instructions a specified number of times.	No forward references No external references Absolute Fixed
REPTC	Repeats and substitutes characters.	
REPTI	Repeats and substitutes text.	

Table 18: Macro processing directives

A macro is a user-defined symbol that represents a block of one or more assembler source lines. Once you have defined a macro, you can use it in your program like an assembler directive or assembler mnemonic.

When the assembler encounters a macro, it looks up the macro's definition, and inserts the lines that the macro represents as if they were included in the source file at that position.

Macros perform simple text substitution effectively, and you can control what they substitute by supplying parameters to them.

The macro process consists of three distinct phases:

- 1 The assembler scans and saves macro definitions. The text between `MACRO` and `ENDM` is saved but not syntax checked. Include-file references `$file` are recorded and included during macro expansion.
- 2 A macro call forces the assembler to invoke the macro processor (expander). The macro expander switches (if not already in a macro) the assembler input stream from a source file to the output from the macro expander. The macro expander takes its input from the requested macro definition.

The macro expander has no knowledge of assembler symbols since it only deals with text substitutions at source level. Before a line from the called macro definition is handed over to the assembler, the expander scans the line for all occurrences of symbolic macro arguments, and replaces them with their expansion arguments.

- 3 The expanded line is then processed as any other assembler source line. The input stream to the assembler continues to be the output from the macro processor, until all lines of the current macro definition have been read.

Defining a macro

You define a macro with the statement:

```
name MACRO [argument] [,argument] ...
```

Here *name* is the name you are going to use for the macro, and *argument* is an argument for values that you want to pass to the macro when it is expanded.

For example, you could define a macro `errMac` as follows:

```
errMac      macro    text
             call    abort
             db      text, 0
             endm
```

This macro uses a parameter `text` to set up an error message for a routine `abort`. You would call the macro with a statement such as:

```
errMac 'Disk not ready'
```

The assembler expands this to:

```
call abort
db 'Disk not ready',0
even
```

If you omit a list of one or more arguments, the arguments you supply when calling the macro are called `\1` to `\9` and `\A` to `\Z`.

The previous example could therefore be written as follows:

```
errMac macro text
call abort
db \1,0
endm
```

Use the `EXITM` directive to generate a premature exit from a macro.

`EXITM` is not allowed inside `REPT...ENDR`, `REPTC...ENDR`, or `REPTI...ENDR` blocks.

Use `LOCAL` to create symbols local to a macro. The `LOCAL` directive must be used before the symbol is used.

Each time that a macro is expanded, new instances of local symbols are created by the `LOCAL` directive. Therefore, it is legal to use local symbols in recursive macros.

Note: It is illegal to redefine a macro.

Passing special characters

Macro arguments that include commas or white space can be forced to be interpreted as one argument by using the matching quote characters `<` and `>` in the macro call.

For example:

```
macld macro op
mov op
endm
```

The macro can be called using the macro quote characters:

```
ldaMac <R6,#3>
end
```

You can redefine the macro quote characters with the `-M` command line option; see *-M*, page 46.

Predefined macro symbols

The symbol `_args` is set to the number of arguments passed to the macro. This example shows how `_args` can be used:

```
fill      macro
          if      _args == 2
          rept    \2
          dc8     \1
          endr
          else
          dc8     \1
          endif
          endm

          module  filler
          rseg    CODE:CODE
          fill    3
          fill    4, 3
          end
```

It generates this code:

11	000000	module	filler
12	000000	rseg	CODE:CODE
13	000000	fill	3
13.1	000000	if	_args == 2
13.2	000000	rept	
13.3	000000	dc8	3
13.4	000000	endr	
13.5	000000	else	
13.6	000000 03	dc8	3
13.7	000001	endif	
13.8	000001	endm	
14	000001	fill	4, 3
14.1	000001	if	_args == 2
14.2	000001	rept	3
14.3	000001	dc8	4
14.4	000001	endr	
14.5	000001 04	dc8	4
14.6	000004	else	
14.7	000004	dc8	4
14.8	000004	endif	
14.9	000004	endm	
15	000004	end	

Repeating statements

Use the `REPT . . ENDR` structure to assemble the same block of instructions several times. If `expr` evaluates to 0 nothing is generated.

Use `REPTC` to assemble a block of instructions once for each character in a string. If the string contains a comma it should be enclosed in quotation marks.

Only double quotes have a special meaning and their only use is to enclose the characters to iterate over. Single quotes have no special meaning and are treated as any ordinary character.

Use `REPTI` to assemble a block of instructions once for each string in a series of strings. Strings containing commas should be enclosed in quotation marks.

This example assembles a series of calls to a subroutine `plotc` to plot each character in a string:

```

                                name    reptc
                                extern  plotc

banner    reptc    chr, "Welcome"
           mov     R6, 'chr'
           call   plotc
           endr
           end

```


This produces this code:

```

1      000000      name      reptc
2      000000      extern   plotc
3      000000
4      000000      banner   reptc   chr, "Welcome"
5      000000      mov      R6, 'chr'
6      000000      call     plotc
7      000000      endr
7.1    000000 AE57      mov      R6, 'W'
7.2    000002 12....      call     plotc
7.3    000005 AE65      mov      R6, 'e'
7.4    000007 12....      call     plotc
7.5    00000A AE6C      mov      R6, 'l'
7.6    00000C 12....      call     plotc
7.7    00000F AE63      mov      R6, 'c'
7.8    000011 12....      call     plotc
7.9    000014 AE6F      mov      R6, 'o'
7.10   000016 12....      call     plotc
7.11   000019 AE6D      mov      R6, 'm'
7.12   00001B 12....      call     plotc
7.13   00001E AE65      mov      R6, 'e'
7.14   000020 12....      call     plotc
8      000023      end

```

This example uses REPTI to clear several memory locations:

```

      name      repti
      extern   base, count, init, func

banner  repti   adds, base, count, init
        mov    R0, LOW(adds)
        mov    R1, HIGH(adds)
        call   func
        endr

      end

```

This produces this code:

```

1      000000      name      repti
2      000000      extern   base, count, init,
                               func
3      000000
4      000000      banner   repti   adds, base, count,
                               init
5      000000      mov      R0,LOW( adds)
6      000000      mov      R1,HIGH( adds)
7      000000      call     func
8      000000      endr
8.1    000000 A8..      mov      R0,LOW( base)
8.2    000002 A9..      mov      R1,HIGH( base)
8.3    000004 12....      call     func
8.4    000007 A8..      mov      R0,LOW( count)
8.5    000009 A9..      mov      R1,HIGH( count)
8.6    00000B 12....      call     func
8.7    00000E A8..      mov      R0,LOW( init)
8.8    000010 A9..      mov      R1,HIGH( init)
8.9    000012 12....      call     func
9      000015
10     000015      end

```

Coding inline for efficiency

In time-critical code it is often desirable to code routines inline to avoid the overhead of a subroutine call and return. Macros provide a convenient way of doing this.

This example outputs bytes from a buffer to a port:

```

                               name      play
                               rseg      xdata
buffer      ds      256

                               rseg      CODE
play      mov      DPTR, #LWRD(buffer)
                               mov      R5, #255
loop      movx     A, @DPTR
                               mov      P1, A
                               inc      DPTR
                               djnz    R5, loop
                               ret
                               end

```

The main program calls this routine as follows:

```
doPlay      call     play
```

For efficiency we can recode this using a macro:

```

                name    play
                public  main

                rseg    xdata
buffer          ds      256

play           macro
                local   loop
                mov     DPTR, #LWRD(buffer)
                mov     R5, #255
loop           movx    A, @DPTR
                mov     P1, A
                inc     DPTR
                djnz    R5, loop
                ret
                endm

                rseg    CODE
main           play
                end

```

Notice the use of the `LOCAL` directive to make the label `loop` local to the macro; otherwise an error is generated if the macro is used twice, as the `loop` label already exists.

Listing control directives

Syntax	<code>COL columns</code>
	<code>LSTCND{+ -}</code>
	<code>LSTCOD{+ -}</code>
	<code>LSTEXP{+ -}</code>
	<code>LSTMAC{+ -}</code>
	<code>LSTOUT{+ -}</code>
	<code>LSTPAG{+ -}</code>
	<code>LSTREP{+ -}</code>
	<code>LSTSAS{+ -}</code>
	<code>LSTXRF{+ -}</code>

	PAGE	
	PAGSIZ <i>lines</i>	
Parameters	<i>columns</i>	An absolute expression in the range 80 to 132, default is 80
	<i>lines</i>	An absolute expression in the range 10 to 150, default is 44
Description	These directives provide control over the assembler list file:	

Directive	Description
COL	Sets the number of columns per page.
LSTCND	Controls conditional assembly listing.
LSTCOD	Controls multi-line code listing.
LSTEXP	Controls the listing of macro-generated lines.
LSTMAC	Controls the listing of macro definitions.
LSTOUT	Controls assembly-listing output.
LSTPAG	Controls the formatting of output into pages.
LSTREP	Controls the listing of lines generated by repeat directives.
LSTSAS	Controls structured assembler listing.
LSTXRF	Generates a cross-reference table.
PAGE	Generates a new page.
PAGSIZ	Sets the number of lines per page.

Table 19: Listing control directives

Turning the listing on or off

Use `LSTOUT-` to disable all list output except error messages. This directive overrides all other listing control directives.

The default is `LSTOUT+`, which lists the output (if a list file was specified).

To disable the listing of a debugged section of program:

```
lstout-
; This section has already been debugged.
lstout+
; This section is currently being debugged.
end
```

Listing conditional code and strings

Use `LSTCND+` to force the assembler to list source code only for the parts of the assembly that are not disabled by previous conditional `IF` statements.

The default setting is `LSTCND-`, which lists all source lines.

Use `LSTCOD-` to restrict the listing of output code to just the first line of code for a source line.

The default setting is `LSTCOD+`, which lists more than one line of code for a source line, if needed; that is, long ASCII strings produce several lines of output. Code generation is not affected.

This example shows how `LSTCND+` hides a call to a subroutine that is disabled by an `IF` directive:

```

                                name    lstcndTest
                                extern  print

                                rseg    prom

debug    set    0
begin    if    debug
         call   print
         endif

                                lstcnd+
begin2   if    debug
         call   print
         endif

                                end

```

This generates the following listing:

```

1      000000          name      lstcndTest
2      000000          extern    print
3      000000
4      000000          rseg      prom
5      000000
6      000000          debug     set      0
7      000000          begin     if      debug
8      000000                                call    print
9      000000                                endif
10     000000
11     000000          lstcnd+
12     000000          begin2    if      debug
14     000000                                endif
15     000000
16     000000          end

```

Controlling the listing of macros

Use `LSTEXP-` to disable the listing of macro-generated lines. The default is `LSTEXP+`, which lists all macro-generated lines.

Use `LSTMAC+` to list macro definitions. The default is `LSTMAC-`, which disables the listing of macro definitions.

This example shows the effect of `LSTMAC` and `LSTEXP`:

```

dec2      macro      arg
           dec       arg
           dec       arg
           endm

           lstmac+
inc2      macro      arg
           inc       arg
           inc       arg
           endm

begin:
           dec2      R6

           lstexp-
           inc2      R7
           ret
           end

```

This produces the following output:

```

5      000000
6      000000
7      000000          inc2          lstmac+
8      000000          macro      arg
9      000000          inc        arg
10     000000          endm
11     000000
12     000000          begin:
13     000000          dec2      R6
13.1   000000 1E      dec        R6
13.2   000001 1E      dec        R6
13.3   000002          endm
14     000002
15     000002          lstexp-
16     000002          inc2      R7
17     000004 22      ret
18     000005          end

```

Controlling the listing of generated lines

Use `LSTREP-` to turn off the listing of lines generated by the directives `REPT`, `REPTC`, and `REPTI`.

The default is `LSTREP+`, which lists the generated lines.

Generating a cross-reference table

Use `LSTXRF+` to generate a cross-reference table at the end of the assembler list for the current module. The table shows values and line numbers, and the type of the symbol.

The default is `LSTXRF-`, which does not give a cross-reference table.

Specifying the list file format

Use `COL` to set the number of columns per page of the assembler list. The default number of columns is 80.

Use `PAGSIZ` to set the number of printed lines per page of the assembler list. The default number of lines per page is 44.

Use `LSTPAG+` to format the assembler output list into pages.

The default is `LSTPAG-`, which gives a continuous listing.

Use `PAGE` to generate a new page in the assembler list file if paging is active.

C-style preprocessor directives

Syntax	<pre>#define <i>symbol text</i> #elif <i>condition</i> #else #endif #error "<i>message</i>" #if <i>condition</i> #ifdef <i>symbol</i> #ifndef <i>symbol</i> #include {"<i>filename</i>" <<i>filename</i>>} #line <i>line-no</i> {"<i>filename</i>"} #message "<i>message</i>" #undef <i>symbol</i></pre>												
Parameters	<table> <tr> <td style="vertical-align: top;"><i>condition</i></td> <td>An absolute assembler expression, see <i>Expressions, operands, and operators</i>, page 20. The expression must not contain any assembler labels or symbols, and any non-zero value is considered as true. The C preprocessor operator <code>defined</code> can be used.</td> </tr> <tr> <td style="vertical-align: top;"><i>filename</i></td> <td>Name of file to be included or referred.</td> </tr> <tr> <td style="vertical-align: top;"><i>line-no</i></td> <td>Source line number.</td> </tr> <tr> <td style="vertical-align: top;"><i>message</i></td> <td>Text to be displayed.</td> </tr> <tr> <td style="vertical-align: top;"><i>symbol</i></td> <td>Preprocessor symbol to be defined, undefined, or tested.</td> </tr> <tr> <td style="vertical-align: top;"><i>text</i></td> <td>Value to be assigned.</td> </tr> </table>	<i>condition</i>	An absolute assembler expression, see <i>Expressions, operands, and operators</i> , page 20. The expression must not contain any assembler labels or symbols, and any non-zero value is considered as true. The C preprocessor operator <code>defined</code> can be used.	<i>filename</i>	Name of file to be included or referred.	<i>line-no</i>	Source line number.	<i>message</i>	Text to be displayed.	<i>symbol</i>	Preprocessor symbol to be defined, undefined, or tested.	<i>text</i>	Value to be assigned.
<i>condition</i>	An absolute assembler expression, see <i>Expressions, operands, and operators</i> , page 20. The expression must not contain any assembler labels or symbols, and any non-zero value is considered as true. The C preprocessor operator <code>defined</code> can be used.												
<i>filename</i>	Name of file to be included or referred.												
<i>line-no</i>	Source line number.												
<i>message</i>	Text to be displayed.												
<i>symbol</i>	Preprocessor symbol to be defined, undefined, or tested.												
<i>text</i>	Value to be assigned.												
Description	<p>The assembler has a C-style preprocessor that is similar to the C89 standard. These C-language preprocessor directives are available:</p>												

Directive	Description
<code>#define</code>	Assigns a value to a preprocessor symbol.

Table 20: C-style preprocessor directives

Directive	Description
<code>#elif</code>	Introduces a new condition in an <code>#if...#endif</code> block.
<code>#else</code>	Assembles instructions if a condition is false.
<code>#endif</code>	Ends an <code>#if</code> , <code>#ifdef</code> , or <code>#ifndef</code> block.
<code>#error</code>	Generates an error.
<code>#if</code>	Assembles instructions if a condition is true.
<code>#ifdef</code>	Assembles instructions if a preprocessor symbol is defined.
<code>#ifndef</code>	Assembles instructions if a preprocessor symbol is undefined.
<code>#include</code>	Includes a file.
<code>#line</code>	Changes the source references in the debug information.
<code>#message</code>	Generates a message on standard output.
<code>#pragma</code>	This directive is recognized but ignored.
<code>#undef</code>	Undefines a preprocessor symbol.

Table 20: C-style preprocessor directives (Continued)

You should not mix assembler language and C-style preprocessor directives. Conceptually, they are different languages and mixing them might lead to unexpected behavior because an assembler directive is not necessarily accepted as a part of the C preprocessor language.

Note that the preprocessor directives are processed before other directives. As an example avoid constructs like:

```
redef      macro                ; Avoid the following!
#define \1 \2
          endm
```

because the `\1` and `\2` macro arguments are not available during the preprocessing phase.

Defining and undefining preprocessor symbols

Use `#define` to define a value of a preprocessor symbol.

```
#define symbol value
```

Use `#undef` to undefine a symbol; the effect is as if it had not been defined.

Conditional preprocessor directives

Use the `#if...#else...#endif` directives to control the assembly process at assembly time. If the condition following the `#if` directive is not true, the subsequent instructions will not generate any code (that is, it will not be assembled or syntax checked) until an `#endif` or `#else` directive is found.

All assembler directives (except for `END`) and file inclusion can be disabled by the conditional directives. Each `#if` directive must be terminated by an `#endif` directive. The `#else` directive is optional and, if used, it must be inside an `#if...#endif` block.

`#if...#endif` and `#if...#else...#endif` blocks can be nested to any level.

Use `#ifdef` to assemble instructions up to the next `#else` or `#endif` directive only if a symbol is defined.

Use `#ifndef` to assemble instructions up to the next `#else` or `#endif` directive only if a symbol is undefined.

This example defines the labels `tweak` and `adjust`. If `adjust` is defined, then register 16 is decremented by an amount that depends on `adjust`, in this case 30.

```
#define      tweak  1
#define      adjust 3

#ifdef     tweak
    mov     A,R6
    clr     C
    #if     adjust==1
        subb    A,#4
    #elif   adjust==2
        subb    A,#20
    #elif   adjust==3
        subb    A,#30
    #endif
    mov     R6,A
#endif
/* ifdef tweak */
```

Including source files

Use `#include` to insert the contents of a header file into the source file at a specified point.

`#include "filename"` and `#include <filename>` search these directories in the specified order:

- 1 The source file directory. (This step is only valid for `#include "filename"`.)
- 2 The directories specified by the `-I` option, or options. The directories are searched in the same order as specified on the command line, followed by the ones specified by environment variables.
- 3 The current directory, which is the same as where the assembler executable file is located.
- 4 The automatically set up library system include directories. See `-g`, page 44.

This example uses `#include` to include a file defining macros into the source file. For example, these macros could be defined in `Macros.inc`:

```
xch      macro   a,b
          push   a
          mov    a,b
          pop    b
          endm
```

The macro definitions can then be included, using `#include`, as in this example:

```
          name    include

; Standard macro definitions.
#include "Macros.inc"

; program
main     xch      DPL, DPH
          ret
          end main
```

Displaying errors

Use `#error` to force the assembler to generate an error, such as in a user-defined test.

Ignoring `#pragma`

A `#pragma` line is ignored by the assembler, making it easier to have header files common to C and assembler.

Changing the source line numbers

Use the `#line` directive to change the source line numbers and the source filename used in the debug information. `#line` operates on the lines following the `#line` directive.

Comments in C-style preprocessor directives

If you make a comment within a define statement, use:

- the C comment delimiters `/* ... */` to comment sections
- the C++ comment delimiter `//` to mark the rest of the line as comment.

Do not use assembler comments within a define statement as it leads to unexpected behavior.

This expression evaluates to 3 because the comment character is preserved by #define:

```
#define x 3      ; This is a misplaced comment.

                module misplacedComment1
expression equ  x * 8 + 5
                ; ...
                end
```

This example illustrates some problems that might occur when assembler comments are used in the C-style preprocessor:

```
#define five 5      ; This comment is not OK.
#define six 6      // This comment is OK.
#define seven 7    /* This comment is OK. */

                module misplacedComment2
                rseg  CONST:CONST(2)

                DC32  five, 11, 12
; The previous line expands to:
;      "DC32  5      ; This comment is not OK., 11, 12"

                DC32  six + seven, 11, 12
; The previous line expands to:
;      "DC32  6 + 7, 11, 12"

                end
```

Data definition or allocation directives

Syntax	DB <i>expr</i> [, <i>expr</i>] ...
	DC8 <i>expr</i> [, <i>expr</i>] ...
	DC16 <i>expr</i> [, <i>expr</i>] ...
	DC24 <i>expr</i> [, <i>expr</i>] ...
	DC32 <i>expr</i> [, <i>expr</i>] ...
	DD <i>expr</i> [, <i>expr</i>] ...
	DS.[<i>size</i>] <i>count</i>
	DS <i>count</i>
	DS8 <i>count</i>
	DS16 <i>count</i>
	DS24 <i>count</i>
	DS32 <i>count</i>
	DT <i>expr</i> [, <i>expr</i>] ...
	DW <i>expr</i> [, <i>expr</i>] ...

Parameters

<i>count</i>	A valid absolute expression specifying the number of elements to be reserved.
<i>expr</i>	A valid absolute, relocatable, or external expression, or an ASCII string. ASCII strings are zero filled to a multiple of the data size implied by the directive. Double-quoted strings are zero-terminated.

Description

These directives define values or reserve memory.

Use `DC8`, `DC16`, `DC24`, or `DC32` to create a constant, which means an area of bytes is reserved big enough for the constant.

Use `DS8`, `DS16`, `DS24`, or `DS32` to reserve a number of uninitialized bytes.

For information about the restrictions that apply when using a directive in an expression, see *Expression restrictions*, page 25.

The column *Alias* in the following table shows old-style directives that correspond to the directives.

Directive	Alias	Description
<code>DC8</code>	<code>DB</code>	Generates 8-bit constants, including strings.
<code>DC16</code>	<code>DW</code>	Generates 16-bit constants.
<code>DC24</code>	<code>DT</code>	Generates 24-bit constants.
<code>DC32</code>	<code>DD</code>	Generates 32-bit constants.
<code>DS8</code>	<code>DS</code>	Allocates space for 8-bit integers.
<code>DS16</code>		Allocates space for 16-bit integers.
<code>DS24</code>		Allocates space for 24-bit integers.
<code>DS32</code>		Allocates space for 32-bit integers.

Table 21: Data definition or allocation directives

Generating a lookup table

This example generates a lookup table of addresses to routines:

```

                                name    table
table      dc8      addsubr,subsubr,clrsubr
addsubr    add      A,R7
           ret
subsubr    subb     A,R7
           ret
clrsubr    clr      A
           ret
           end

```

Defining strings

To define a string:

```
myMsg  DC8 'Please enter your name'
```

To define a string which includes a trailing zero:

```
myCstr DC8 "This is a string."
```

To include a single quote in a string, enter it twice; for example:

```
errMsg DC8 'Don't understand!'
```

Reserving space

To reserve space for 10 bytes:

```
table  DS8  10
```

Assembler control directives

Syntax	<i>\$filename</i>
	<i>/*comment*/</i>
	<i>//comment</i>
	CASEOFF
	CASEON
	RADIX <i>expr</i>

Parameters

<i>comment</i>	Comment ignored by the assembler.
<i>expr</i>	Default base; default 10 (decimal).
<i>filename</i>	Name of file to be included. The <code>\$</code> character must be the first character on the line.

Description

These directives provide control over the operation of the assembler. For information about the restrictions that apply when using a directive in an expression, see *Expression restrictions*, page 25.

Directive	Description	Expression restrictions
<code>\$</code>	Includes a file.	
<code>/*comment*/</code>	C-style comment delimiter.	
<code>//</code>	C++ style comment delimiter.	
<code>CASEOFF</code>	Disables case sensitivity.	
<code>CASEON</code>	Enables case sensitivity.	
<code>RADIX</code>	Sets the default base on all numeric values.	No forward references No external references Absolute Fixed

Table 22: Assembler control directives

Use `$` to insert the contents of a file into the source file at a specified point. This is an alias for `#include`.

Use `/* . . . */` to comment sections of the assembler listing.

Use `//` to mark the rest of the line as comment.

Use `RADIX` to set the default base for constants. The default base is 10.

Controlling case sensitivity

Use `CASEON` or `CASEOFF` to turn on or off case sensitivity for user-defined symbols. By default, case sensitivity is off.

When `CASEOFF` is active all symbols are stored in upper case, and all symbols used by `XLINK` should be written in upper case in the `XLINK` definition file.

When `CASEOFF` is set, `label` and `LABEL` are identical in this example:

```
label      nop                ; Stored as "LABEL".
           jmp      LABEL
```

The following will generate a duplicate label error:

```
label      nop                ; Stored as "LABEL".
LABEL     nop                ; Error, "LABEL" already defined.
end
```

Including a source file

This example uses `$` to include a file defining macros into the source file. For example, these macros could be defined in `Macros.inc`:

```
xch      macro  a,b
          push  a
          mov   a,b
          pop   b
endm
```

The macro definitions can be included with a `$` directive, as in:

```
          name   include

; Standard macro definitions.
$Macros.inc

; program
main
          xch   DPL,DPH
          ret
end main
```

Defining comments

This example shows how `/*...*/` can be used for a multi-line comment:

```
/*
Program to read serial input.
Version 1: 19.2.11
Author: mjp
*/
```

See also *C-style preprocessor directives*, page 104.

Changing the base

To set the default base to 16:

```

module radix
rseg CODE

radix D'16 ; With the default base set
mov A,#12 ; to 16, the immediate value
;... ; of the move instruction is
; interpreted as H'12.
end

```

; To reset the base from 16 to 10 again, the argument must be
; written in hexadecimal format.

```

radix 0x0A ; Reset the default base to 10.
mov A,#12 ; Now, the immediate value of
;... ; the move instruction is
; interpreted as 0x0C.
end

```

Function directives

Syntax

```

ARGFRAME segment, size, type
FUNCALL caller, callee
FUNCTION label, value
LOCFRAME segment, size, type

```

Parameters

<i>callee</i>	The called function.
<i>caller</i>	The caller to a function.
<i>label</i>	A label to be declared as function.
<i>segment</i>	The segment in which argument frame or local frame is to be stored.
<i>size</i>	The size of the argument frame or the local frame.
<i>type</i>	The type of argument or local frame; either <code>STACK</code> or <code>STATIC</code> .
<i>value</i>	Function information.

Description

The function directives are generated by the IAR C/C++ Compiler for 8051 to pass information about functions and function calls to the IAR XLINK Linker. These directives can be seen if you create an assembler list file by using the compiler option **Output assembler file>Include compiler runtime information (-1A)**.

Note: These directives are primarily intended to support static overlay, a feature which is useful in smaller microcontrollers.

Directive	Description
FUNCTION	Declares the <i>label</i> name to be a function. <i>value</i> encodes extra information about the function. After a FUNCTION directive for an external function, there can only be ARGFRAME directives, which indicate the maximum argument frame usage of any call to that function. After a FUNCTION directive for a defined function, there can be both ARGFRAME and LOCFRAME directives.
FUNCALL	Declares that the function <i>caller</i> calls the function <i>callee</i> . <i>callee</i> can be omitted to indicate an indirect function call. After a FUNCALL directive, there will first be LOCFRAME directives declaring frame usage in the falling function at the point of the call, and then ARGFRAME directives declaring argument frame usage of the called function.
ARGFRAME LOCFRAME	Declare how much space the frame of the function uses in different memories. ARGFRAME declares the space used for the arguments to the function, LOCFRAME the space for locals. <i>segment</i> is the segment in which the space resides. <i>size</i> is the number of bytes used. <i>type</i> is either STACK or STATIC, for stack-based allocation and static overlay allocation, respectively. ARGFRAME and LOCFRAME always occur immediately after a FUNCTION or FUNCALL directive.
CASEON	Enables case sensitivity.
RADIX	Sets the default base on all numeric values.

Table 23: Function directives

Call frame information directives for names blocks

Syntax

Names block directives:

```
CFI NAMES name
```

```
CFI ENDNAMES name
```

```
CFI RESOURCE resource : bits [, resource : bits] ...
```

```
CFI VIRTUALRESOURCE resource : bits [, resource : bits] ...
CFI RESOURCEPARTS resource part, part [, part] ...
CFI STACKFRAME cfa resource type [, cfa resource type] ...
CFI STATICOVERLAYFRAME cfa segment [, cfa segment] ...
CFI BASEADDRESS cfa type [, cfa type] ...
```

Extended names block directives:

```
CFI NAMES name EXTENDS namesblock
CFI ENDNAMES name
CFI FRAMECELL cell cfa(offset):size [, cell cfa(offset):size] ...
```

Parameters

<i>bits</i>	The size of the resource in bits.
<i>cell</i>	The name of a frame cell.
<i>cfa</i>	The name of a CFA (canonical frame address).
<i>name</i>	The name of the block.
<i>namesblock</i>	The name of a previously defined names block.
<i>offset</i>	The offset relative the CFA. An integer with an optional sign.
<i>part</i>	A part of a composite resource. The name of a previously declared resource.
<i>resource</i>	The name of a resource.
<i>segment</i>	The name of a segment.
<i>size</i>	The size of the frame cell in bytes.
<i>type</i>	The segment memory type, such as CODE, CONST or DATA. In addition, any of the memory types supported by the IAR XLINK Linker. It is only used for denoting an address space.

Description

Use these directives to define a names block:

Directive	Description
CFI BASEADDRESS	Declares a base address CFA (Canonical Frame Address).
CFI ENDNAMES	Ends a names block.
CFI FRAMECELL	Creates a reference into the caller's frame.

Table 24: Call frame information directives names block

Directive	Description
CFI NAMES	Starts a names block.
CFI RESOURCE	Declares a resource.
CFI RESOURCEPARTS	Declares a composite resource.
CFI STACKFRAME	Declares a stack frame CFA.
CFI STATICOVERLAYFRAME	Declares a static overlay frame CFA.
CFI VIRTUALRESOURCE	Declares a virtual resource.

Table 24: Call frame information directives names block (Continued)

Example	<i>Examples of using CFI directives, page 35</i>
See also	<i>Tracking call frame usage, page 28</i>

Call frame information directives for common blocks

Syntax

Common block directives:

CFI COMMON *name* USING *namesblock*

CFI ENDCOMMON *name*

CFI CODEALIGN *codealignfactor*

CFI DATAALIGN *dataalignfactor*

CFI RETURNADDRESS *resource type*

Extended common block directives:

CFI COMMON *name* EXTENDS *commonblock* USING *namesblock*

CFI ENDCOMMON *name*

Parameters

codealignfactor The smallest common factor of all instruction sizes. Each CFI directive for a data block must be placed according to this alignment. 1 is the default and can always be used, but a larger value reduces the produced call frame information in size. The possible range is 1–256.

commonblock The name of a previously defined common block.

<i>dataalignfactor</i>	The smallest common factor of all frame sizes. If the stack grows toward higher addresses, the factor is negative; if it grows toward lower addresses, the factor is positive. 1 is the default, but a larger value reduces the produced call frame information in size. The possible ranges are -256 to -1 and 1 to 256 .
<i>name</i>	The name of the block.
<i>namesblock</i>	The name of a previously defined names block.
<i>resource</i>	The name of a resource.
<i>type</i>	The memory type, such as CODE, CONST or DATA. In addition, any of the segment memory types supported by the IAR XLINK Linker. It is only used for denoting an address space.

Description

Use these directives to define a common block:

Directive	Description
CFI CODEALIGN	Declares code alignment.
CFI COMMON	Starts or extends a common block.
CFI DATAALIGN	Declares data alignment.
CFI ENDCOMMON	Ends a common block.
CFI RETURNADDRESS	Declares a return address column.

Table 25: Call frame information directives common block

In addition to these directives you might also need the call frame information directives for specifying rules or CFI expressions for resources and CFAs, see *Call frame information directives for tracking resources and CFAs*, page 118.

Example

Examples of using CFI directives, page 35

See also

Tracking call frame usage, page 28

Call frame information directives for data blocks

Syntax

```
CFI BLOCK name USING commonblock
CFI ENDBLOCK name
CFI { NOFUNCTION | FUNCTION label }
CFI { INVALID | VALID }
CFI { REMEMBERSTATE | RESTORESTATE }
```

	CFI PICKER	
	CFI CONDITIONAL <i>label</i> [, <i>label</i>] ...	
Parameters	<i>commonblock</i>	The name of a previously defined common block.
	<i>label</i>	A function label.
	<i>name</i>	The name of the block.
Description	These directives allow call frame information to be defined in the assembler source code:	

Directive	Description
CFI BLOCK	Starts a data block.
CFI CONDITIONAL	Declares a data block to be a conditional thread.
CFI ENDBLOCK	Ends a data block.
CFI FUNCTION	Declares a function associated with a data block.
CFI INVALID	Starts a range of invalid call frame information.
CFI NOFUNCTION	Declares a data block to not be associated with a function.
CFI PICKER	Declares a data block to be a picker thread. Used by the compiler for keeping track of execution paths when code is shared within or between functions.
CFI REMEMBERSTATE	Remembers the call frame information state.
CFI RESTORESTATE	Restores the saved call frame information state.
CFI VALID	Ends a range of invalid call frame information.

Table 26: Call frame information directives for data blocks

In addition to these directives you might also need the call frame information directives for specifying rules or CFI expressions for resources and CFAs, see *Call frame information directives for tracking resources and CFAs*, page 118.

Example *Examples of using CFI directives*, page 35

See also *Tracking call frame usage*, page 28

Call frame information directives for tracking resources and CFAs

Syntax

```
CFI cfa { resource | resource + constant | resource - constant }
CFI cfa cfiexpr
```

```
CFI resource { UNDEFINED | SAMEVALUE | CONCAT }
CFI resource { resource | FRAME(cfa, offset) }
CFI resource cfiexpr
```

Parameters

<i>cfa</i>	The name of a CFA (canonical frame address).
<i>cfiexpr</i>	A CFI expression, which can be one of these: <ul style="list-style-type: none"> ● A CFI operator with operands ● A numeric constant ● A CFA name ● A resource name.
<i>constant</i>	A constant value or an assembler expression that can be evaluated to a constant value.
<i>offset</i>	The offset relative the CFA. An integer with an optional sign.
<i>resource</i>	The name of a resource.

Unary operators

Overall syntax: *OPERATOR*(*operand*)

CFI operator	Operand	Description
COMPLEMENT	<i>cfiexpr</i>	Performs a bitwise NOT on a CFI expression.
LITERAL	<i>expr</i>	Get the value of the assembler expression. This can insert the value of a regular assembler expression into a CFI expression.
NOT	<i>cfiexpr</i>	Negates a logical CFI expression.
UMINUS	<i>cfiexpr</i>	Performs arithmetic negation on a CFI expression.

Table 27: Unary operators in CFI expressions

Binary operators

Overall syntax: *OPERATOR*(*operand1*, *operand2*)

CFI operator	Operands	Description
ADD	<i>cfiexpr</i> , <i>cfiexpr</i>	Addition
AND	<i>cfiexpr</i> , <i>cfiexpr</i>	Bitwise AND
DIV	<i>cfiexpr</i> , <i>cfiexpr</i>	Division
EQ	<i>cfiexpr</i> , <i>cfiexpr</i>	Equal
GE	<i>cfiexpr</i> , <i>cfiexpr</i>	Greater than or equal

Table 28: Binary operators in CFI expressions

CFI operator	Operands	Description
GT	<i>cfiexpr, cfiexpr</i>	Greater than
LE	<i>cfiexpr, cfiexpr</i>	Less than or equal
LSHIFT	<i>cfiexpr, cfiexpr</i>	Logical shift left of the left operand. The number of bits to shift is specified by the right operand. The sign bit will not be preserved when shifting.
LT	<i>cfiexpr, cfiexpr</i>	Less than
MOD	<i>cfiexpr, cfiexpr</i>	Modulo
MUL	<i>cfiexpr, cfiexpr</i>	Multiplication
NE	<i>cfiexpr, cfiexpr</i>	Not equal
OR	<i>cfiexpr, cfiexpr</i>	Bitwise OR
RSHIFTA	<i>cfiexpr, cfiexpr</i>	Arithmetic shift right of the left operand. The number of bits to shift is specified by the right operand. In contrast with RSHIFTL, the sign bit is preserved when shifting.
RSHIFTL	<i>cfiexpr, cfiexpr</i>	Logical shift right of the left operand. The number of bits to shift is specified by the right operand. The sign bit will not be preserved when shifting.
SUB	<i>cfiexpr, cfiexpr</i>	Subtraction
XOR	<i>cfiexpr, cfiexpr</i>	Bitwise XOR

Table 28: Binary operators in CFI expressions (Continued)

Ternary operators

Overall syntax: *OPERATOR(operand1, operand2, operand3)*

Operator	Operands	Description
FRAME	<i>cfa, size, offset</i>	Gets the value from a stack frame. The operands are: <i>cfa</i> , an identifier that denotes a previously declared CFA. <i>size</i> , a constant expression that denotes a size in bytes. <i>offset</i> , a constant expression that denotes a size in bytes. Gets the value at address <i>cfa+offset</i> of size <i>size</i> .
IF	<i>cond, true, false</i>	Conditional operator. The operands are: <i>cond</i> , a CFI expression that denotes a condition. <i>true</i> , any CFI expression. <i>false</i> , any CFI expression. If the conditional expression is non-zero, the result is the value of the <i>true</i> expression; otherwise the result is the value of the <i>false</i> expression.

Table 29: Ternary operators in CFI expressions

Operator	Operands	Description
LOAD	<i>size, type, addr</i>	Gets the value from memory. The operands are: <i>size</i> , a constant expression that denotes a size in bytes. <i>type</i> , a memory type. <i>addr</i> , a CFI expression that denotes a memory address. Gets the value at address <i>addr</i> in the segment memory type <i>type</i> of size <i>size</i> .

Table 29: Ternary operators in CFI expressions (Continued)

Description

Use these directives to track resources and CFAs in common blocks and data blocks:

Directive	Description
CFI <i>cfa</i>	Declares the value of a CFA.
CFI <i>resource</i>	Declares the value of a resource.

Table 30: Call frame information directives for tracking resources and CFAs

Example

Examples of using CFI directives, page 35

See also

Tracking call frame usage, page 28

Assembler diagnostics

The following pages describe the format of the diagnostic messages and explains how diagnostic messages are divided into different levels of severity.

Message format

All diagnostic messages are displayed on the screen, and printed in the optional list file.

All messages are issued as complete, self-explanatory messages. The message consists of the incorrect source line, with a pointer to where the problem was detected, followed by the source line number and the diagnostic message. If include files are used, error messages are preceded by the source line number and the name of the current file:

```
          ADS      B,C
-----^
"subfile.h",4  Error[40]: bad instruction
```

Severity levels

The diagnostic messages produced by the IAR Assembler for 8051 reflect problems or errors that are found in the source code or occur at assembly time.

OPTIONS FOR DIAGNOSTICS

There are two assembler options for diagnostics. You can:

- Disable or enable all warnings, ranges of warnings, or individual warnings, see *-w*, page 53
- Set the number of maximum errors before the compilation stops, see *-E*, page 43.

ASSEMBLY WARNING MESSAGES

Assembly warning messages are produced when the assembler finds a construct which is probably the result of a programming error or omission.

COMMAND LINE ERROR MESSAGES

Command line errors occur when the assembler is invoked with incorrect parameters. The most common situation is when a file cannot be opened, or with duplicate, misspelled, or missing command line options.

ASSEMBLY ERROR MESSAGES

Assembly error messages are produced when the assembler finds a construct which violates the language rules.

ASSEMBLY FATAL ERROR MESSAGES

Assembly fatal error messages are produced when the assembler finds a user error so severe that further processing is not considered meaningful. After the diagnostic message is issued, the assembly is immediately ended. These error messages are identified as `Fatal` in the error messages list.

ASSEMBLER INTERNAL ERROR MESSAGES

An internal error is a diagnostic message that signals that there was a serious and unexpected failure due to a fault in the assembler.

During assembly, several internal consistency checks are performed and if any of these checks fail, the assembler terminates after giving a short description of the problem. Such errors should normally not occur. However, if you should encounter an error of this type, it should be reported to your software distributor or to IAR Systems Technical Support. Please include information enough to reproduce the problem. This would typically include:

- The product name
- The version number of the assembler, which can be seen in the header of the list files generated by the assembler
- Your license number
- The exact internal error message text
- The source file of the program that generated the internal error
- A list of the options that were used when the internal error occurred.

A

- absolute expressions 25
- absolute segments 83
- ADD (CFI operator) 119
- addition (assembler operator) 59
- address field, in assembler list file 26
- ALIAS (assembler directive) 87
- ALIGN (assembler directive) 83
- alignment, of segments 86
- ALIGNRAM (assembler directive) 83
- AND (CFI operator) 119
- ARGFRAME (assembler directive) 113–114
- _args (assembler directive) 92
- _args (predefined macro symbol) 95
- ASCII character constants 21
- ASEG (assembler directive) 83
- ASEGN (assembler directive) 83
- asm (filename extension) 17
- assembler BLOCK (assembler directive) 79
- assembler control directives 110
- assembler diagnostics 123
- assembler directives
 - assembler control 110
 - CFI directives for common blocks 116
 - CFI directives for data blocks 117
 - CFI directives for names blocks 114
 - CFI directives for tracking resources and CFAs 118
 - conditional assembly 90
 - See also* C-style preprocessor directives
 - C-style preprocessor 104
 - data definition or allocation 108
 - function 113
 - list file control 99
 - macro processing 91
 - module control 75
 - segment control 81
 - summary 71
 - symbol control 79
 - value assignment 86
- assembler environment variables 18
- assembler expressions 20
- assembler invocation syntax 17
- assembler labels 22
 - format of 19
- assembler list files
 - address field 26
 - comments 111
 - conditional code and strings 101
 - cross-references
 - generating (LSTXRF) 103
 - generating (-x) 54
 - data field 27
 - enabling and disabling (LSTOUT) 100
 - filename, specifying (-l) 46
 - generated lines, controlling (LSTREP) 103
 - generating (-L) 45
 - header section, omitting (-N) 47
 - #include files, specifying (-i) 45
 - lines per page, specifying (-p) 49
 - macro execution information, including (-B) 41
 - macro-generated lines, controlling 102
 - symbol and cross-reference table 27
 - tab spacing, specifying 51
 - using directives to format 103
- assembler macros
 - arguments, passing to 95
 - defining 93
 - generated lines, controlling in list file 102
 - inline routines 98
 - predefined symbol 95
 - quote characters, specifying 46
 - special characters, using 94
- assembler object file, specifying filename 48
- assembler operators 55
 - in expressions 20
 - precedence 55

assembler options	
passing to assembler	18
command line, setting	39
extended command file, setting	40
specifying parameters	39
summary	40
assembler output, including debug information	50
assembler source files, including	106, 112
assembler source format	19
assembler subversion number	24
assembler symbols	22
exporting	80
importing	80–81
in relocatable expressions	25
local	89
predefined	23
undefining	51
assembling, invocation syntax	17
assembly error messages	124
assembly messages format	123
assembly warning messages	123
disabling	53
ASSIGN (assembler directive)	87
assumptions (programming experience)	11
A8051_INC (environment variable)	18

B

-B (assembler option)	41
bitwise AND (assembler operator)	62
bitwise exclusive OR (assembler operator)	63
bitwise NOT (assembler operator)	62
bitwise OR (assembler operator)	62
BLOCK (assembler directive)	79
bold style, in this guide	13
__BUILD_NUMBER__ (predefined symbol)	23
BYTE2 (assembler operator)	64
BYTE3 (assembler operator)	65
BYTE4 (assembler operator)	65

C

-c (assembler option)	42
call frame information directives	114, 116–118
case sensitive user symbols	50
case sensitivity, controlling	111
CASEOFF (assembler directive)	111
CASEON (assembler directive)	111, 114
CFA, CFI directives for tracking	118
CFI BASEADDRESS (assembler directive)	115
CFI BLOCK (assembler directive)	118
CFI cfa (assembler directive)	121
CFI CODEALIGN (assembler directive)	117
CFI COMMON (assembler directive)	117
CFI CONDITIONAL (assembler directive)	118
CFI DATAALIGN (assembler directive)	117
CFI directives for common blocks	116
CFI directives for data blocks	117
CFI directives for names blocks	114
CFI directives for tracking resources and CFAs	118
CFI ENDBLOCK (assembler directive)	118
CFI ENDCOMMON (assembler directive)	117
CFI ENDNAMES (assembler directive)	115
CFI expressions	34
CFI FRAMECELL (assembler directive)	115
CFI FUNCTION (assembler directive)	118
CFI INVALID (assembler directive)	118
CFI NAMES (assembler directive)	116
CFI NOFUNCTION (assembler directive)	118
CFI PICKER (assembler directive)	118
CFI REMEMBERSTATE (assembler directive)	118
CFI RESOURCE (assembler directive)	116
CFI resource (assembler directive)	121
CFI RESOURCEPARTS (assembler directive)	116
CFI RESTORESTATE (assembler directive)	118
CFI RETURNADDRESS (assembler directive)	117
CFI STACKFRAME (assembler directive)	116
CFI STATICOVERLAYFRAME (assembler directive)	116
CFI VALID (assembler directive)	118

CFI VIRTUALRESOURCE (assembler directive) 116

character constants, ASCII 21

CLIB

- naming convention 14

COL (assembler directive) 100

command line error messages, assembler 123

command line options 39

- part of invocation syntax 17
- passing 18
- typographic convention 13

command line, extending 43

command prompt icon, in this guide 13

comments

- in assembler list file 111
- in assembler source code 19
- in C-style preprocessor directives 107
- multi-line, using with assembler directives 112

common block (call frame information) 29

common blocks, CFI directives for 116

common block, defining 31

common segments 85

COMMON (assembler directive) 83

COMPLEMENT (CFI operator) 119

computer style, typographic convention 12

conditional assembly directives 90

- See also* C-style preprocessor directives

conditional code and strings, listing 101

constants

- default base of 111
- integer 20

conventions, used in this guide 12

copyright notice 2

CRC, in assembler list file 27

cross-references, in assembler list file

- generating (LSTXRF) 103
- generating (-x) 54

current time/date (assembler operator) 65

C-style preprocessor directives 104

C++ terminology 12

D

-D (assembler option) 42

data allocation directives 108

data block (call frame information) 30

data blocks, CFI directives for 117

data definition directives 108

data field, in assembler list file 27

__DATE__ (predefined symbol) 23

DATE (assembler operator) 65

DB (assembler directive) 109

DC8 (assembler directive) 109

DC16 (assembler directive) 109

DC24 (assembler directive) 109

DC32 (assembler directive) 109

DD (assembler directive) 109

debug information, including in assembler output 50

default base, for constants 111

#define (assembler directive) 104

DEFINE (assembler directive) 87

defining a common block 31

defining a names block 30

diagnostic messages

- options for 123

diagnostics 123

directives. *See* assembler directives

disclaimer 2

DIV (CFI operator) 119

division (assembler operator) 60

DLIB

- naming convention 13

document conventions 12

DS (assembler directive) 109

DS8 (assembler directive) 109

DS16 (assembler directive) 109

DS24 (assembler directive) 109

DS32 (assembler directive) 109

DT (assembler directive) 109

DW (assembler directive) 109

E

-E (assembler option)	43
edition, of this guide	2
efficient coding techniques	27
#elif (assembler directive)	105
#else (assembler directive)	105
END (assembler directive)	76
#endif (assembler directive)	105
ENDM (assembler directive)	92
ENDMOD (assembler directive)	76
ENDR (assembler directive)	92
environment variables	
assembler	18
A8051_INC	18
EQ (CFI operator)	119
EQU (assembler directive)	87
equal (assembler operator)	61
#error (assembler directive)	105
error messages	
format	123
maximum number, specifying	43
#error, using to display	107
EVEN (assembler directive)	83
EXITM (assembler directive)	92
experience, programming	11
expressions	20
extended command line file (extend.xcl)	40, 43
EXTERN (assembler directive)	79

F

-f (assembler option)	40, 43
false value, in assembler expressions	21
fatal errors	124
__FILE__ (predefined symbol)	23
file extensions. <i>See</i> filename extensions	
file types	
assembler output	17

assembler source	17
extended command line	40, 43
#include, specifying path	44
filename extensions	
asm	17
msa	17
r51	17
s51	17
xcl	40, 43
filenames, specifying for assembler object file	48–49
floating-point constants	21
formats	
assembler source code	19
diagnostic messages	123
in list files	26
fourth byte (assembler operator)	65
FRAME (CFI operator)	120
FUNCALL (assembler directive)	113–114
function directives	113
FUNCTION (assembler directive)	113–114

G

-G (assembler option)	44
-g (assembler option)	44
GE (CFI operator)	119
global value, defining	88
greater than or equal (assembler operator)	61
greater than (assembler operator)	61
GT (CFI operator)	120

H

header files, SFR	27
header section, omitting from assembler list file	47
high byte (assembler operator)	66
high word (assembler operator)	66
HIGH (assembler operator)	66
HWRD (assembler operator)	66

- I**
- I (assembler option) 44
 - __IAR_SYSTEMS_ASM__ (predefined symbol) 23
 - icons, in this guide 13
 - #if (assembler directive) 105
 - IF (CFI operator) 120
 - #ifdef (assembler directive) 105
 - #ifndef (assembler directive) 105
 - IMPORT (assembler directive) 79
 - #include files 45
 - #include files, specifying 44
 - #include (assembler directive) 105
 - include files, disabling search for 44
 - include paths, specifying 44
 - inline coding, using macros 98
 - installation directory 12
 - integer constants 20
 - internal errors, assembler 124
 - invocation syntax 17
 - italic style, in this guide 12–13
- L**
- L (assembler option) 45
 - l (assembler option) 46
 - labels. *See* assembler labels
 - LE (CFI operator) 120
 - less than or equal (assembler operator) 60
 - less than (assembler operator) 60
 - library modules 77
 - LIBRARY (assembler directive) 74, 76
 - lightbulb icon, in this guide 13
 - LIMIT (assembler directive) 87
 - __LINE__ (predefined symbol) 23
 - #line (assembler directive) 105
 - lines per page, in assembler list file 49
 - linker options
 - typographic convention 12
 - list file format 26
 - body 26
 - CRC 27
 - header 26
 - symbol and cross reference
 - list files
 - control directives for 99
 - controlling contents of (-c) 42
 - cross-references, generating (-x) 54
 - filename, specifying (-l) 46
 - generating (-L) 45
 - header section, omitting (-N) 47
 - #include files, specifying (-i) 45
 - LITERAL (CFI operator) 119
 - LOAD (CFI operator) 121
 - LOC (assembler operator) 66
 - local value, defining 88
 - LOCAL (assembler directive) 92
 - location counter. *See* program location counter
 - LOCFRAME (assembler directive) 113–114
 - logical AND (assembler operator) 62
 - logical exclusive OR (assembler operator) 70
 - logical NOT (assembler operator) 63
 - logical OR (assembler operator) 64
 - logical shift left (assembler operator) 64
 - logical shift right (assembler operator) 64
 - low byte (assembler operator) 67
 - low word (assembler operator) 67
 - LOW (assembler operator) 67
 - LSHIFT (CFI operator) 120
 - LSTCND (assembler directive) 100
 - LSTCOD (assembler directive) 100
 - LSTEXP (assembler directives) 100
 - LSTMAC (assembler directive) 100
 - LSTOUT (assembler directive) 100
 - LSTPAG (assembler directive) 100
 - LSTREP (assembler directive) 100
 - LSTSAS (assembler directive) 100
 - LSTXRF (assembler directive) 100

LT (CFI operator)	120
LWRD (assembler operator)	67

M

-M (assembler option)	46
macro execution information, including in list file	41
macro processing directives	91
macro quote characters	94
specifying	46
MACRO (assembler directive)	92
macros. <i>See</i> assembler macros	
memory, reserving space in	109
#message (assembler directive)	105
messages, excluding from standard output stream	50
MOD (CFI operator)	120
module consistency	78
module control directives	75
MODULE (assembler directive)	76
modules	
assembling multi-modules files	78
terminating	77
modules, beginning	77
msa (filename extension)	17
MUL (CFI operator)	120
multibyte character support	47
multiplication (assembler operator)	58

N

-N (assembler option)	47
-n (assembler option)	47
NAME (assembler directive)	76
names block (call frame information)	29
names blocks, CFI directives for	114
names block, defining	30
naming conventions	13
NE (CFI operator)	120
not equal (assembler operator)	61

NOT (CFI operator)	119
--no_path_in_file_macros (assembler option)	48

O

-O (assembler option)	48
-o (assembler option)	49
ODD (assembler directive)	83
operands	
format of	19
in assembler expressions	20
operations, format of	19
operation, silent	50
operators. <i>See</i> assembler operators	
option summary	40
OR (CFI operator)	120
ORG (assembler directive)	83
OVERLAY (assembler directive)	79

P

-p (assembler option)	49
PAGE (assembler directive)	100
PAGSIZ (assembler directive)	100
parameters	
specifying	39
typographic convention	12
part number, of this guide	2
PLC. <i>See</i> program location counter	
#pragma (assembler directive)	105
precedence, of assembler operators	55
predefined register symbols	23
predefined symbols	23
in assembler macros	95
undefining	51
preprocessor symbols	
defining and undefining	105
defining on command line	42
prerequisites (programming experience)	11

PRM (assembler operator)	67
processor configuration, specifying	52
program counter. <i>See</i> program location counter	
program entry	77
program location counter (PLC)	22
setting	85
program modules, beginning.	77
PROGRAM (assembler directive)	76
programming experience, required	11
programming hints	27
PUBLIC (assembler directive)	80
publication date, of this guide	2
PUBWEAK (assembler directive)	80

R

-r (assembler option)	50
RADIX (assembler directive)	111, 114
reference information, typographic convention.	13
registered trademarks	2
registers	23
special function, defining.	89
relocatable expressions	25
relocatable segments, beginning	84
repeating statements	96
REPT (assembler directive)	92
REPTC (assembler directive)	92
REPTI (assembler directive)	92
REQUIRE (assembler directive)	80
resources, CFI directives for tracking	118
RSEG (assembler directive)	83
RSHIFTA (CFI operator)	120
RSHIFTL (CFI operator)	120
RTMODEL (assembler directive)	76
rules, in CFI directives	32
runtime model attributes, declaring	78
r51 (filename extension)	17

S

-S (assembler option)	50
-s (assembler option).	50
second byte (assembler operator)	64
segment begin (assembler operator)	68
segment control directives	81
segment end (assembler operator)	68
segment size (assembler operator)	69
segments	
absolute	83
aligning	86
common, beginning	85
relocatable	84
SET (assembler directive)	87
SFB (assembler operator)	68
SFE (assembler operator)	68
SFRTYPE (assembler directive)	87
SFR. <i>See</i> special function registers	
silent operation, specifying in assembler.	50
simple rules, in CFI directives	32
SIZEOF (assembler operator)	69
source files	
example of including	112
including	106
source format, assembler	19
source line numbers, changing	107
special function registers.	27
defining labels	89
STACK (assembler directive)	83
standard input stream (stdin), reading from.	44
standard output stream, disabling messages to	50
statements, repeating.	96
SUB (CFI operator)	120
subtraction (assembler operator)	59
__SUBVERSION__ (predefined symbol)	24
symbol and cross-reference table, in assembler list file	27
<i>See also</i> Include cross-reference	
symbol control directives	79

symbol values, checking	90
SYMBOL (assembler directive)	80
symbols	
<i>See also</i> assembler symbols	
exporting to other modules	80
predefined, in assembler	23
predefined, in assembler macro	95
user-defined, case sensitive	50
system include files, disabling search for	44
--system_include_dir (assembler option)	51
s51 (filename extension)	17

T

-t (assembler option)	51
tab spacing, specifying in assembler list file	51
temporary values, defining	87
terminology.	12
third byte (assembler operator)	65
__TID__ (predefined symbol)	24
__TIME__ (predefined symbol)	24
time-critical code	98
tools icon, in this guide	13
trademarks	2
true value, in assembler expressions	21
typographic conventions	12

U

-U (assembler option)	51
UGT (assembler operator)	69
ULT (assembler operator)	70
UMINUS (CFI operator)	119
unary minus (assembler operator)	59
unary plus (assembler operator)	59
#undef (assembler directive)	105
unsigned greater than (assembler operator)	69
unsigned less than (assembler operator)	70
user symbols, case sensitive	50

V

-v (assembler option)	52
value assignment directives	86
values, defining.	109
__VER__ (predefined symbol)	24
version	
of this guide	2

W

-w (assembler option)	53
warnings	123
disabling	53
warnings icon, in this guide	13

X

-x (assembler option)	54
xcl (filename extension)	40, 43
XOR (assembler operator)	70
XOR (CFI operator)	120

Symbols

_args (assembler directive)	92
_args (predefined macro symbol)	95
__BUILD_NUMBER__ (predefined symbol)	23
__DATE__ (predefined symbol)	23
__FILE__ (predefined symbol)	23
__IAR_SYSTEMS_ASM__ (predefined symbol)	23
__LINE__ (predefined symbol)	23
__SUBVERSION__ (predefined symbol)	24
__TID__ (predefined symbol)	24
__TIME__ (predefined symbol)	24
__VER__ (predefined symbol)	24
- (assembler operator)	59
-B (assembler option)	41
-c (assembler option)	42

-D (assembler option)	42
-E (assembler option)	43
-f (assembler option)	40, 43
-G (assembler option)	44
-g (assembler option)	44
-I (assembler option)	44
-i (assembler option)	45
-L (assembler option)	45
-l (assembler option)	46
-M (assembler option)	46
-N (assembler option)	47
-n (assembler option)	47
-O (assembler option)	48
-o (assembler option)	49
-p (assembler option)	49
-r (assembler option)	50
-S (assembler option)	50
-s (assembler option)	50
-t (assembler option)	51
-U (assembler option)	51
-v (assembler option)	52
-w (assembler option)	53
-x (assembler option)	54
--no_path_in_file_macros (assembler option)	48
--system_include_dir (assembler option)	51
! (assembler operator)	63
!= (assembler operator)	61
() (assembler operator)	58
* (assembler operator)	58
/ (assembler operator)	60
/*...*/ (assembler directive)	111
// (assembler directive)	111
& (assembler operator)	62
&& (assembler operator)	62
#define (assembler directive)	104
#elif (assembler directive)	105
#else (assembler directive)	105
#endif (assembler directive)	105
#error (assembler directive)	105
#if (assembler directive)	105
#ifdef (assembler directive)	105
#ifndef (assembler directive)	105
#include files	45
#include files, specifying	44
#include (assembler directive)	105
#line (assembler directive)	105
#message (assembler directive)	105
#pragma (assembler directive)	105
#undef (assembler directive)	105
^ (assembler operator)	63
+ (assembler operator)	59
< (assembler operator)	60
<< (assembler operator)	64
<= (assembler operator)	60
<> (assembler operator)	61
= (assembler directive)	87
= (assembler operator)	61
== (assembler operator)	61
> (assembler operator)	61
>= (assembler operator)	61
>> (assembler operator)	64
(assembler operator)	62
(assembler operator)	64
~ (assembler operator)	62
\$ (assembler directive)	111
\$ (program location counter)	22